



## BusWorks® 900EN Series – Modbus TCP/IP 10/100M Industrial Ethernet I/O Modules

Model 965EN-4006 6 Channel mV/TC Input  
Model 965EN-4004 4 Channel mV/TC Input

### USER'S MANUAL



ACROMAG INCORPORATED  
30765 South Wixom Road  
Wixom, MI 48393-2417 U.S.A.

Tel (Process): (248) 295-0880  
Fax: (248) 624-9234

Copyright 2003-2014, Acromag, Inc., Printed in the USA.  
Data and specifications are subject to change without notice.

8500719L

## TABLE OF CONTENTS

Symbols on equipment:



Means "Refer to User's Manual (this manual) for additional information".

*The information of this manual may change without notice. Acromag makes no warranty of any kind with regard to this material, including, but not limited to, the implied warranties of merchantability and fitness for a particular purpose. Further, Acromag assumes no responsibility for any errors that may appear in this manual and makes no commitment to update, or keep current, the information contained in this manual. No part of this manual may be copied or reproduced in any form without the prior written consent of Acromag, Inc.*

*For additional information, please visit our web site at [www.acromag.com](http://www.acromag.com) and download our whitepaper 8500-765, Introduction To Modbus TCP/IP, or 8500-648, Introduction to Modbus.*

Windows® is a registered trademark of Microsoft Corporation.

## IMPORTANT SAFETY CONSIDERATIONS

You must consider the possible negative effects of power, wiring, sensor, component, or software failure in the design of any type of monitoring or control system. This is very important where property loss or human life is involved. It is important that you perform satisfactory overall system design and it is agreed between you and Acromag, that this is your responsibility.

## GETTING STARTED

<b>QUICK START</b> .....	3
<b>MOUNTING AND DIMENSIONS</b> .....	5
<b>CONTROLS &amp; INDICATORS</b> .....	5
<b>ISOLATION BARRIERS</b> .....	5
<b>CONNECTIONS</b> .....	6
<b>DIN-Rail Mounting And Removal</b> .....	6
<b>Network</b> .....	6
<b>Power</b> .....	8
<b>Analog Inputs</b> .....	8
<b>Earth Ground</b> .....	8
<b>WEB BROWSER</b> .....	9
<b>Home Page</b> .....	9
<b>Password Configuration Page</b> .....	10
<b>Network Configuration Page</b> .....	10
<b>I/O Mapping Page (Optional i2o Function)</b> .....	13
<b>Test Page</b> .....	15
<b>Calibration Page</b> .....	16
<b>Input Calibration</b> .....	18
<b>CJC Calibration</b> .....	19
<b>0° Offset Null (Optional)</b> .....	21
<b>TROUBLESHOOTING</b> .....	23
<b>Diagnostics Table</b> .....	23
<b>Trouble Browsing Your Module?</b> .....	24
<b>Getting Out Of Trouble</b> .....	24

## TECHNICAL REFERENCE

<b>KEY FEATURES</b> .....	25
<b>HOW IT WORKS</b> .....	26
<b>ABOUT MODBUS TCP/IP</b> .....	27
<b>IP Addressing</b> .....	27
<b>Dynamic Host Configuration Protocol</b> .....	29
<b>MODBUS REGISTERS</b> .....	29
<b>Register Functions</b> .....	29
<b>Register Mirroring</b> .....	30
<b>Data Types</b> .....	31
<b>Register Map</b> .....	32
<b>SPECIFICATIONS</b> .....	42
<b>Model Numbers</b> .....	42
<b>Analog Inputs</b> .....	42
<b>General Specifications</b> .....	43
<b>Enclosure and Physical</b> .....	44
<b>Agency Approvals</b> .....	44
<b>Environmental</b> .....	44
<b>Ethernet Interface</b> .....	46
<b>Controls &amp; Indicators</b> .....	46
<b>ACCESSORY CABLES</b> .....	47
<b>REVISION HISTORY</b> .....	49

If you already know the basics of connecting power, connecting a network cable, and using a web-browser, and you only need some help establishing communication. Here is a brief outline of what you must do to start communicating with this device right away and where to go for help.

This is an Ethernet device with built-in web capability. This allows you to use your web-browser to set it up and configure it. All Ethernet devices have a unique IP address that you are required to know in order to use your web-browser to actually communicate with it.

What if you do not already know the IP address of the unit?

All Acromag Ethernet devices include an alternate default mode of operation with a fixed IP address set to **128.1.1.100**. Additionally, the user-programmable IP address that is used outside of default mode is also initially set to 128.1.1.100 from the factory. If this unit is factory fresh, you can talk to it at this address in either mode.

If your unit is not factory fresh and may have another IP address set, then...

You need to place the unit in its Default Mode, which allows you to address it at IP address 128.1.1.100 (<http://128.1.1.100>).

Place this unit into Default Mode by depressing the front-panel toggle switch to the position marked "DFT" (left) for about 4 seconds, just until the yellow ST LED starts blinking slowly to indicate the unit is in the Default Mode.

Try browsing the unit with your web browser address at <http://128.1.1.100>. If your unit is in default mode, you should be presented with the home page, similar to that shown at right.

If you are using IP address 128.1.1.100, and you still can't talk to the unit...




You cannot talk to this device at IP address 128.1.1.100 if the Network Interface Card (NIC) you are using to connect to this device is set to an IP address outside of the address domain established by the default address. That is, you must set the IP address of your network interface to an address like 128.1.1.x, where x is an integer from 1 to 254, except 100 (our default address). This procedure is covered in document 8500-815 shipped with your unit. It is also detailed in Application Note 8500-734, which you can obtain from the CDROM shipped with your unit, or optionally via download from our web site at [www.acromag.com](http://www.acromag.com).

You managed to browse to the unit's Home Page, but now you need to get to the Network Configuration Page to set your own IP address...

In order to access any of the other web configuration pages, like the Network Configuration Page, you will need to first enter a Username = **User**, and Password = **password00** to gain access (these are the default username and password settings for all 9xxEN models and these entries are case-sensitive). The password query window is shown at right.

## QUICK START

### Guide to Quickly Establishing Communication



## QUICK START

### Guide to Quickly Establishing Communication

A properly powered and connected unit should have both green LED's ON (RUN and LINK).

*Your unit is not factory-fresh and you do not know the Username and Password settings...*

If you forget your user name & password, you can always toggle the unit into default mode via the DFT toggle switch at the front of the unit (hold this toggle to the left DFT position about 4 seconds to invoke default mode). In this mode, the password and username will revert to the original defaults of "User" and "password00" (the unit assumes an IP address of 128.1.1.100 in its default mode), allowing you to re-invoke the Password Configuration Page and change the username and password settings as required.

*If after applying power and connecting your network cable, your green Link LED does not turn ON, then you need to do the following:*

If the RUN LED is ON and the LINK LED is OFF, verify that your network cable is connected to both the unit and to your PC.

If the RUN LED is ON and the LINK LED is OFF, verify that your network cable is of the right type (cross-over).

*The Ethernet port of this module is wired MDI, and requires that you use a crossover cable to connect it to your PC or another device wired MDI. If you happen to be connecting to an Ethernet switch or hub, then a direct cable may be used, as these devices are auto-crossing.*

*Note that even if the green Link LED is ON, then you have indeed connected using the correct cable type, but the cable could still be defective and prevent communication.*

*If after applying power, your green Run LED does not turn ON at all, or blinks continuously, then you need to do the following:*

When you first power up, the green Run LED will blink until the unit completes its initialization sequence, then remain ON.


If the green RUN LED does not turn ON at all, check your power connections, voltage polarity, voltage level, and current capacity.

If the RUN LED blinks continuously after 30 seconds, try resetting the unit by momentarily depressing the DFT/RST toggle switch to the right/RST position. After several seconds, the RUN LED should remain ON.

If you have checked your power level and you tried resetting the unit, but the green RUN LED still blinks continuously, then you may need to follow the procedure for restoring the unit to its Initial Configuration. This procedure is located at the end of the Trouble-Shooting section of this manual under "Getting Out Of Trouble".


At this point, if the green RUN LED continues to blink, this may be indicative of a problem with the internal program and you may need to return the unit for repair.

If you need additional help and you have already reviewed the material in this manual, please contact the factory.




NOTE: Dimensions Are INCHES (MILLIMETERS).

MODEL 965EN ENCLOSURE DIMENSIONS



The toggle switch is used to toggle the module into or out of Default Mode (toggle left), or to reset the module (toggle right). In Default Communication Mode, the yellow ST LED blinks slowly and the module assumes a fixed static IP address of "128.1.1.100", a default subnet mask of "255.255.255.0", a default username of "User", and a default password of "password00".



### MOUNTING AND DIMENSIONS

Unit mounts to "T" type DIN rails (35mm, type EN50022).

Units may be mounted side-by-side on 1-inch centers.

**WARNING:** IEC Safety Standards may require that this device be mounted within an approved metal enclosure or sub-system, particularly for applications with exposure to voltages greater than or equal to 75VDC or 50VAC.

### CONTROLS & INDICATORS

Green Run LED is ON if power is on and will blink in "wink" ID mode.

Yellow ST LED blinks ON/OFF if module is in default mode and stays ON if an input is out of range.

Green LINK LED ON if auto-negotiation has successfully established a connection.

Yellow ACT LED signals PHY network Activity (busy).

### ISOLATION BARRIERS


Dashed Lines denote isolation barriers.

The input circuit, network, and power circuit are isolated from each other for safety and noise immunity.

## CONNECTIONS

### DIN-Rail Mounting & Removal

When attaching the module to the T-type DIN rail, angle the top of the unit towards the rail and locate the top groove of the adapter over the upper lip of the rail. Firmly push the unit towards the rail until it snaps into place. To remove, first separate the input terminal block(s) from the bottom side of the module to create a clearance to the DIN mounting area. Next, while holding the module in place from above, insert a screwdriver into the lower arm of the DIN rail connector and use it as a lever to force the connector down until the unit disengages from the rail (do not twist the screwdriver to avoid damaging plastic).



### Network

For 100Base-TX systems, use data grade Unshielded Twisted-Pair (UTP) wiring that has a 100Ω characteristic impedance and meets the EIA/TIA Category Five wire specifications.


It is recommended that you use a crossover CAT-5/5E cable to connect this device to your PC.

For 10Base-T systems, you may use Category 3, Category 4, or Category 5/5E UTP/STP cable.

In either case, you are limited to 100 meters between any two devices.

A crossover cable simply connects the differential transmit pair on each end, to the receive pair on the opposite end.

Use a standard (direct) cable when connecting to a hub or switch port, which are generally wired MDI-X.




RJ45 MDI CONNECTIONS

1	Transmit +
2	Transmit -
3	Receive +
4	Not Used
5	Not Used
6	Receive -
7	Not Used
8	Not Used

SPEED	DISTANCE	CABLE
10Base-T	100M	CAT 3, CAT 4, or CAT 5 UTP
100Base-TX	100M	CAT 5/5e UTP/STP

The Ethernet port of this module is wired MDI and does not include automatic crossover. The Ethernet port of your PC is also wired MDI and may not include automatic crossover. As such, you must use a crossover cable like that shown below when connecting this device directly to a PC.

### CROSSOVER CABLE FOR MDI TO MDI OR MDI-X TO MDI-X




Refer to the Accessory Cables section at the back of this manual for more information on accessory cables, including patch and crossover cables available from Acromag and other vendors.

## CONNECTIONS

### Network

#### HOST PC CONNECTED DIRECTLY TO A MODULE

Note: This MDI-to-MDI connection requires the use of a crossover cable.




Acromag 983EN-4012 Ethernet Module.

The ethernet port of this module is not automatic MDI/MDI-X crossover and is wired MDI.

**TIP:** You can significantly enhance the EMI/RFI performance of your network connections by using Category 5E STP cable (Shielded Twisted Pair) with shielded RJ45 plug connectors. This will also help to protect your installation from damage due to ESD (Electro-Static Discharge). The use of shielded cable is strongly recommended for installations in harsh industrial environments and/or in the presence of strong electrical fields.

You can use an Ethernet switch or switching hub to build a network of Ethernet modules, similar to that shown below. This drawing shows how to network-connect Acromag Series 9xxEN modules to a 5-port Ethernet switch (Acromag Model 900EN-S005). Note that the 900EN-S005 switch includes automatic MDI/MDI-X crossover and a straight-through or crossover cable(s) may be used to connect to the modules and the PC.



#### USE OF AN ETHERNET SWITCH TO NETWORK A HOST PC TO MORE THAN ONE MODULE

The ethernet port of the PC is generally not automatic MDI/MDI-X crossover and is wired MDI.

Because the Acromag ethernet switch 900EN-S005 is automatic MDI/MDI-X crossover, use of a direct (straight-through) or crossover cable is permissible.

Acromag 900EN-S005 5-Port Ethernet Switch or equivalent.

The ethernet ports of this switch are automatic MDI/MDI-X crossing and do not require crossover cables.

Acromag 9xxEN-4012 Ethernet Modules.

The ethernet port of these modules are not automatic MDI/MDI-X crossover, but the use of an auto-crossing switch eliminates the need to make a distinction between straight-through and crossover cables.

**IMPORTANT:** IF THE HOST PC CONNECTS DIRECTLY TO THE MODULE, YOU MUST USE A CROSS-CONNECT CABLE (MDI-X), AS BOTH THE PC AND THE 9XXEN MODULE ETHERNET PORTS ARE WIRED MDI.

ETHERNET SWITCHES AND HUBS ARE WIRED MDI-X. THE ACROMAG ETHERNET SWITCH IS AUTOMATIC MDI/MDI-X AND ELIMINATES THE NEED FOR MAKING A DISTINCTION BETWEEN THE USE OF STRAIGHT-THROUGH (MDI) AND Crossover (MDI-X) CABLE CONNECTIONS.


Acromag offers a straight-through patch cable (Model 5035-355), or a crossover cable (Model 5035-360) for use with Series 9xxEN modules.

## CONNECTIONS

### Power

Voltage	Current
15VDC	120mA
18VDC	100mA
24VDC	78mA
36VDC	57mA

- ✓ Connect 15-36V DC to the power terminals labeled DC+ & DC-. Observe proper polarity. For supply connections, use No. 14 AWG wires rated for at least 75°C. **CAUTION:** Do not exceed 36VDC peak.



INPUT POWER IS ISOLATED

NOTE: For rated performance and adherence to applicable standards, you must connect earth ground to the GND terminal at TB3-33 as shown.

**CAUTION: Risk of Electric Shock** – More than one disconnect switch may be required to de-energize equipment before servicing.

**IMPORTANT – External Fuse:** If unit is powered from a supply capable of delivering more than 1A to the unit, it is recommended that this current be limited via a high surge tolerant fuse rated for a maximum current of 1A or less (for example, see Bel Fuse MJS1).


### Analog Inputs

Input is a type J, K, T, E, R, S, B, or N thermocouple, ±100mV DC, or ±1V DC.

Ground inputs as shown.

Inputs are not isolated channel-to-channel, except for small common mode difference voltages up to ±4V peak.

- ✓ Connect analog input signals to the input terminals as shown below according to your model.



NOTE 1: This ground connection is recommended for best results. If your sensors are inherently connected to ground, use caution and avoid making additional ground connections which could generate ground loops and measurement error.

NOTE 2: Shielded cable is recommended. For best results, ground the cable shield at the end of the cable closest to the greatest potential source of EMC disturbance.

### Earth Ground

**Warning:** To comply with safety and performance standards, use shielded cable and connect earth ground as noted. Failure to use good wiring and grounding practices may be unsafe and hurt performance.

- ✓ Connect Earth Ground as shown in the connection drawings above. Additionally, always connect the GND terminal (TB3-33) to earth ground.

The ground connections noted are recommended for best results. If sensors are already grounded, use caution and avoid making additional ground connections which could create ground loops.

**TIP:** For best performance, the cable shield ground should be connected at the end that is closest to potential sources of disturbance.


**The plastic module housing does not require earth ground.**




This module supports Modbus over TCP/IP. You may use your own software to issue Modbus command to this module (see Modbus Registers), or you may use a standard web browser, as these modules have built-in web pages that allow you to setup, control, and calibrate the module. Simply execute your web browser, type the IP address assigned to your module in the "Address" window (<http://128.1.1.100/> for our example), click [Go], and you will be presented with a Home Page window similar to that shown below:

## WEB BROWSER

### Home Page




The Home Page provides buttons to access the other web pages of this module that are used to configure the network parameters, change the user name and password, calibrate the module, and operate/test the module. For each new browser session that accesses the Home Page of this module, you will be presented with a window prompting you to enter the current User Name and Password as shown below. This information is required before the program will allow you to make any other selections. **The default user name and password is "User" and "password00" respectively.** After entering these defaults, you may wish to invoke the Password Configuration Page to change these parameters to something more meaningful to you.



**IMPORTANT:** If you forget your installed user name & password, you can always toggle the module into default mode via the default mode toggle switch at the front of the module. Then the password and username will revert to the original defaults noted above, allowing you to re-invoke the Password Configuration Page and change the username and password settings as required.

## WEB BROWSER

### Password Configuration Page




Use up to 20 alphanumeric characters (case sensitive) to specify your username, and 10 alphanumeric characters (case sensitive) to specify a password. You will have to type in these entries twice to help prevent errors. Click the **submit** button to write your changes to the module.

After completing your username/password changes, click on the appropriate button at the bottom of the page to select another web page. If you made changes, you may be prompted to re-enter your new username and password before being permitted to move to other pages.

### Network Configuration

After setting your username and password, you can click the “Network Configuration Page” button to set the network configuration parameters for the module. You may have to consult your network administrator to complete the contents of this page.



An **IP Address** is a unique identification number for any host (this module) on any TCP/IP network (including the internet). The IP address is made up of four octets (8 bits), each octet having a value between 0-255 (00H-FFH). It is expressed here in decimal form, with a period placed between octets.

A **Static IP Address** is as the name implies—*static*, and represents a unique fixed IP Address that is generally assigned by your service provider or system administrator. The default static IP address assigned to this module from the factory is 128.1.1.100 (refer to product side label).

**NOTE:** In order to network your PC with an Acromag module, you may have to consult with your network administrator and either temporarily change your TCP/IP configuration (see TCP/IP Properties of Network Configuration in Windows), or create a separate private network using a second network adapter installed in your PC (recommended). The necessary steps will vary with your operating system. Refer to Acromag Application Note 8500-734 to help accomplish this (located on the CDROM shipped with your module or via download from our web site at [www.acromag.com](http://www.acromag.com)).

The **Number of Sockets** refers to the number (1-10) of Modbus TCP/IP access points to allow for this host. The default allows up to 10 sockets, but you can restrict access by reducing this number. Internally, the module uses port number 502 which is reserved for Modbus.

The **DNS Server** refers to the IP address of the Domain Name Server used on this network. A DNS server relates symbolic names to actual IP addresses, while the DHCP server is responsible for dynamically passing out IP addresses.

A **Subnet Mask** is used to subdivide the host portion of the IP address into two or more subnets. The subnet mask will flag the bits of the IP address that belong to the network address, and the remaining bits correspond to the host portion of the address. The unique subnet to which an IP address refers to is recovered by performing a bitwise AND operation between the IP address and the mask itself, with the result being the sub-network address.

**Gateway** refers to the IP Address of the gateway, if your local area network happens to be isolated by a gateway. Typically, it is assigned the first host address in the subnet. If a gateway is not present, then this field should contain an unused address within the host subnet address range.

The **Host Name** is the name to be assigned to this host if its address happens to be assigned dynamically using DHCP.

The **Active IP Address** refers to the current IP Address being used by this host, as opposed to any new assignments being made via this page.

The **MAC Address** refers to the Media Access Control Address that uniquely identifies the hardware of this device. This is a unique fixed address assigned to this module at the factory. In IEEE 802 networks, the Data Link Control (DLC) layer of the OSI Reference Model is divided into two sublayers: the Logical Link Control (LLC) layer, and the Media Access Control (MAC) layer. The MAC layer interfaces directly with the network media (each different type of network media requires a different MAC layer).

## WEB BROWSER

### Network Configuration

*Note that Acromag Series 9xxEN Ethernet I/O modules may take from 3-30 seconds to boot upon power-up, depending on your network configuration and whether a DHCP server is present.*

*This module can be placed into a default communication mode via the DFT toggle switch at the front of the module.*

*Default Mode uses a static IP address of "128.1.1.100", a default subnet mask of "255.255.255.0", a default username "User", and a default password "password00".*

## WEB BROWSER

### Network Configuration

By default, the module is setup to use **Static IP Addressing and a Static IP Address of 128.1.1.100**. You can optionally choose to have the IP address assigned dynamically via DHCP/BOOTP or DHCP/BOOTP w/Fallbacks.

This will also require that you specify a valid Host Name. Note that DHCP/BOOTP w/Fallback will revert to the static IP address if your DHCP or BOOTP server cannot be found at the address specified.

In general, BOOTP (Bootstrap Protocol) refers to an internet protocol that enables a diskless workstation to discover its own IP address, the address of a BOOTP server on the network, and a file to be loaded into memory to boot the machine. This enables the workstation or device server to boot without requiring a hard or floppy disk drive. BOOTP works similar to DHCP, but is usually found in older systems. This protocol is defined by RFC 951.

DHCP (Dynamic Host Configuration Protocol) refers to a protocol for assigning dynamic IP addresses to devices on a network. With dynamic addressing, a device can have a different IP address every time it connects to the network. In some systems, it can even change while it is still connected. DHCP also supports a combination of static and dynamic IP addresses. DHCP/BOOTP with fallback will revert to static IP addressing if the DHCP or BOOTP server cannot be found.

*The Default Communication Mode uses a static IP address of "128.1.1.100", a default subnet mask of "255.255.255.0", a default username of "User", and a default password of "password00".*

The unit includes a default address toggle switch to cause the module to assume a preset default factory address. This switch is at the front of the module and is used to toggle the module into, or out of Default Mode. If you use the toggle switch at the front of the module to place the module in default mode, then "Default Communications Mode" will be indicated at the bottom of this screen.

Click the **Submit** button to complete any changes made on this page.

Click the **Wink On/Off** button to toggle the module in/out of "wink" ID mode. In this mode, the module's green RUN LED will blink to confirm identification as an aide to locating a specific module on a network.

Refer to the Technical Reference section of this manual to learn more about IP Addressing terms and concepts.

This module includes special messaging functionality (i2o, input-to-output communication) that allows it to send its input level to an output channel on an Acromag 972EN-400x or 973EN-400x analog output module. The I/O Mapping page is used to specify the static IP address of the 972/973EN module to send input data to, the specific Holding Register address of that module (which channel), an update rate, and to set the scaling.

**IMPORTANT:** This module is designed to function as a Modbus TCP/IP slave/server. Normally, Modbus servers are not allowed to initiate messages on their own and may only respond to client/master requests. The I/O mapping function is a special application that may cause confusion for master/client devices linked to the same network. Other master devices should be restricted from attempting to control i2o target devices.

Each input channel of this device may be mapped to one or two output channels of Acromag 972EN-400x (current output), or 973EN-400x (voltage output) modules. The output channel that is to be controlled in this manner is determined by the Map-To Holding Register address specified. The data written will be scaled to percent-of-span units. Subsequent messages will be sent at a periodic rate specified via the update time. Note that the target output channels may still be controlled independently, but their level will be overwritten by subsequent mapped messages when enabled.

**WEB BROWSER**

**I/O Mapping Page (Optional i2o Function)**



*This messaging function works best if the target module(s) are already online and ready to receive messages. It will still work if the target output modules come online after the input module, but may take several minutes to “discover” all the network targets and begin transmitting to them.*

*If the input module or the target module(s) go offline, remote messaging will resume on its own when the connection is re-established, but this “healing” function may take several minutes depending on which device(s) went offline, why, and for how long.*


**Note:** Remote messaging may only be configured via the built-in web browser page as there are no Modbus registers for specifying these parameters.

Channel Number	Update Time(Sec)	Map To IP Address	Map To Holding Register	Input Scaling
0	<input type="text" value="0"/>	<input type="text" value="0.0.0.0"/>	<input type="text" value="40019"/>	<input type="text" value="-210.0"/> deg C = 0%
	<input type="text" value="0"/>	<input type="text" value="0.0.0.0"/>	<input type="text" value="40019"/>	<input type="text" value="760.0"/> deg C = 100%
1	<input type="text" value="0"/>	<input type="text" value="0.0.0.0"/>	<input type="text" value="40020"/>	<input type="text" value="-210.0"/> deg C = 0%
	<input type="text" value="0"/>	<input type="text" value="0.0.0.0"/>	<input type="text" value="40020"/>	<input type="text" value="760.0"/> deg C = 100%
2	<input type="text" value="0"/>	<input type="text" value="0.0.0.0"/>	<input type="text" value="40021"/>	<input type="text" value="-210.0"/> deg C = 0%
	<input type="text" value="0"/>	<input type="text" value="0.0.0.0"/>	<input type="text" value="40021"/>	<input type="text" value="760.0"/> deg C = 100%
3	<input type="text" value="0"/>	<input type="text" value="0.0.0.0"/>	<input type="text" value="40022"/>	<input type="text" value="-210.0"/> deg C = 0%
	<input type="text" value="0"/>	<input type="text" value="0.0.0.0"/>	<input type="text" value="40022"/>	<input type="text" value="760.0"/> deg C = 100%
4	<input type="text" value="0"/>	<input type="text" value="0.0.0.0"/>	<input type="text" value="40023"/>	<input type="text" value="-210.0"/> deg C = 0%
	<input type="text" value="0"/>	<input type="text" value="0.0.0.0"/>	<input type="text" value="40023"/>	<input type="text" value="760.0"/> deg C = 100%
5	<input type="text" value="0"/>	<input type="text" value="0.0.0.0"/>	<input type="text" value="40024"/>	<input type="text" value="-210.0"/> deg C = 0%
	<input type="text" value="0"/>	<input type="text" value="0.0.0.0"/>	<input type="text" value="40024"/>	<input type="text" value="760.0"/> deg C = 100%

## WEB BROWSER

### I/O Mapping Page (Optional i2o Function)

Use the scroll bar on the right to scroll down to the bottom of this screen as shown below:



*The actual data written to the analog output is rescaled to percent-of-span units (a 16-bit signed integer value with resolution of 0.005%/lsb). . For example, -100%, 0% & +100% output will be represented by the decimal values -20000, 0, and 20000, respectively.*

You can map each input channel to one or two analog output channels of another 972EN or 973EN module. The Map To Holding Register determines the output channel it will map to. Since the input signal is in wide-range engineering units, you must also specify the scaling between the input temperature and 0-100% at the output channel.

**Update Time:** Specify a time from 0-90 seconds between messages. Specify 0 to turn mapped messaging OFF.

**Map To IP Address:** This is the Static IP Address of the target output device (a 972/973EN module on the network).

**Map To Holding Register Address:** Specify a valid 4xxxx holding register address in the target device for writing to the output. For the 972/973EN, only addresses 40019 to 40024 will apply and correspond to channels 0-5.


**Input Scaling:** Since the input signal is in temperature units and wide-range, you must select which portion of the input range will map to 0% and 100% at the output.

After completing your username and password assignment, plus your network configuration parameters, you can use the Test Page to operate your module. The Test Page will allow you to read inputs, enable/disable CJC, set break detect direction, and change input ranges of this model. Optionally, you can null any channel-to-channel offsets at 0°C (described in the Offset Null section).


## WEB BROWSER

### Test Page

**TIP:** Viewing a module's web page is treated similar to viewing a web page on the internet. The first time you open a page, its image is stored as a temporary internet file in PC memory. However, each subsequent attempt to view that page will need to automatically update that image, especially when making configuration changes. With Internet Explorer, click the "Internet Options" of the "Tools" menu, select the "General" tab, locate the "Temporary Internet Files" information and click on the "Settings" button. Then select "Automatically" under "Check for newer versions of stored pages:". Then click [OK] to return to the "General" screen, and click [OK] again to save your settings.



Use the scroll bar on the right to scroll down the page as shown below:



## WEB BROWSER

### Test Page

**Note (TC Break):** Internally, TC input values are represented via 16-bit signed integers with a resolution of 0.1°C/lb and a possible range of -3276.8°C to +3276.7°C. As such, a count of 0-7FFFH is a positive number, while 8000-FFFFH is a negative number. The downscale (break) detent is 32768 for all TC types. However, the upscale break over-range count is trimmed to a reasonable range value according to the TC type as follows: 12895 (J), 20068 (K), 6820 (T), 31190 (R), 32767 (S), 20205 (E), 22824 (B), and 21002 (N).

### Calibration Page

**IMPORTANT:** This module has already been calibrated at the factory and recalibration is not normally required, except as necessary to correct for long term component aging, or to satisfy your company's maintenance requirements. Do not attempt to recalibrate this module unless absolutely required, as miscalibration will negatively affect the module's performance.


Note that the 6 or 4 channels of this module are divided into two groups of 3 channels each (ports). A CJC sensor is included for each channel pair. Input signals for each channel (voltage ranges) are indicated to 3 decimal places as shown.

Note that channels 0, 1, & 2, and channels 3, 4, & 5 (every group of 3 channels) share the same input configuration, but the configuration may vary between the two groups. Break detection applies to all channels together. CJC 0 is used for channels 0 & 1, CJC 1 for channels 2 & 3, and CJC 2 for channels 4 & 5.

**IMPORTANT:** The input signal indicated only reflects the level of the inputs at the moment this screen is invoked and this does not continuously update. You can click your browser's refresh button to get a new input update. Note that the ACT LED will blink each time you hit refresh.

You can use the Port Configuration Control of this page to change the input range for the channels on a port-by-port basis. For the 965EN shown, you may select from a voltage range of ±100mV, or ±1V, or TC type J, K, T, R, S, E, B, or N thermocouple. Note that your range selection will apply to all channels of the entire port (group of three channels). You may also select the break detect direction by selecting UP for upscale, or DOWN for downscale (applies to all channels together). Click on "submit" to execute your range and/or TC break changes.

The Calibration Page will allow you to recalibrate each channel's zero and span signal as required. Simply select the channel to be calibrated, choose zero or span, apply the zero or full-scale signal to the input, then click calibrate. For best results, always calibrate zero before span.




Use the scroll bar on the right to scroll down the page as shown below:



**WEB BROWSER**

**Calibration Page**



If recalibration of any input is required, all applicable ranges should be done. The following table gives the calibration values for these models. These represent the input signals required to calibrate the range endpoints.

*Your success in recalibrating the input will strongly depend upon the accuracy and precision of your signal source.*

**Input Calibration Values For Supported Input Ranges**

Available Input Ranges	INPUT CALIBRATION POINTS	
	LOW CALIBRATION POINT (Cal Lo)	HIGH CALIBRATION POINT (Cal Hi)
Type J TC	0.0° (0.000mV)	700.0° (39.130mV)
Type K TC	0.0° (0.000mV)	1300.0° (52.398mV)
Type T TC	0.0° (0.000mV)	390.0° (20.252mV)
Type R TC	0.0° (0.000mV)	1700.0° (20.215mV)
Type S TC	0.0° (0.000mV)	1700.0° (17.942mV)
Type E TC	0.0° (0.000mV)	950.0° (72.593mV)
Type B TC	260° (0.317mV)	1700° (12.426mV)
Type N TC	0.0° (0.000mV)	1200.0° (43.836mV)
±100 mVDC	-100.000 mVDC	100.000 mVDC
±1.00 VDC	-1.00V DC	+1.00V DC

**IMPORTANT:** Be sure to turn CJC off prior to calibrating any TC or voltage ranges. For best results, be sure to use a precision millivoltage source capable of reproducing the nominal thermoelectric endpoint signals at least as accurate as the module itself (better than ±0.1% of span). In addition, always allow the module to warm up several minutes prior to calibration.

## WEB BROWSER

### Calibration Page

There are nine calibration channels for the 965EN-4006, six input channels plus three temperature references (CJC). There are six calibration channels for the 965EN-4004, four input channels plus two temperature references (CJC). Input channels are calibrated differently than temperature reference channels.

Note that because of equivalent A/D gain selections between some ranges, Type K and Type N are calibrated at the same time Type J is calibrated, and Type R and Type S are calibrated at the same time Type T is calibrated. Also, Type J and the  $\pm 1V$  ranges must be calibrated prior to calibrating the CJC references.

### Input Calibration

*You can choose to use the web browser calibration page to accomplish calibration as described in Method 1 at right (easiest), or via direct register access as described in Method 2 below.*

#### **Method 1 – Calibration Using The Built-In Browser Interface:**

1. Make sure that the range that needs calibrating is currently selected.
2. Turn CJC off.
3. Bring up browser interface and select the calibration page.
4. Apply either the Cal LO or Cal HI input signal to the channel to be calibrated. Calibrate the low endpoint signal first, before the high endpoint signal.
5. Wait about 10 seconds for the input to settle and be read.
6. Click on the channel number and select either low or high calibration.
7. Click on the “Calibrate” button. The page will refresh and calibration may continue. Repeat this process for the other endpoint (Cal HI).
8. Repeat steps 4-7 for the other input channels to be calibrated for this same range.
9. Repeat steps 1-7 until all input ranges have been calibrated. Note that Type K and Type N are calibrated by calibrating Type J, and type R and Type S are calibrated by calibrating Type T.

#### **Method 2 - Calibration Via The Modbus TCP/IP Interface:**

1. Write to the TC Break & CJC Configuration Register to turn CJC OFF and set the break detection as required by your application.
2. Write to the appropriate Input Range Register to select the input range to be calibrated for your channel of interest.
3. Write 24106 (5E2AH) into the Calibration Access Register to remove write protection from the calibration registers.
4. Apply the zero calibration signal (Cal Lo, see table) to the input to be calibrated and allow the input to settle about 10 seconds.
5. Write a 16-bit value to the Zero Calibration Register with a set bit in the bit position that corresponds to the channel number to be calibrated (one channel at a time). If you were calibrating the zero of channel 5, you would write 0x0020 to the Zero Calibration Register. The module will replace calibration coefficients immediately, no reset is needed.
6. Apply the full-scale calibration signal (Cal Hi, see table) to the input to be calibrated and allow the input to settle about 10 seconds.
7. Write a 16-bit value to the Span Calibration Register with a set bit in the bit position that corresponds to the channel number of the channel to be calibrated (one channel at a time). For example, if you wanted to calibrate the span of channel 0, write 0x0001 to the “Span Cal Register”.
8. Repeat steps 4-7 for the other channels as required.
9. Repeat steps 2-8 for the next range as required.
10. When finished calibrating, write 0x0000 to the Calibration Access Register (Holding register 21) to replace write protection to the calibration registers and prevent miscalibration.

The 965EN-2004 model includes two CJC reference sensors. The 965EN-2006 model includes three CJC reference sensors. These reference sensors are calibrated separate from the inputs, but use the adjacent input channels 0, 2, and 4, plus the  $\pm 1V$  and Type J TC ranges to accomplish calibration. As such, be sure the Type J TC and  $\pm 1V$  ranges are already calibrated at inputs 0, 2, and 4 prior to calibrating CJC. Then enable CJC and calibrate Cold Junction Compensation as follows:

**IMPORTANT:** For best results, allow the module to warm-up for 60 minutes before calibrating cold junction compensation. Further, position the module as in the final application during warmup. Ambient must be between 10°C and 40°C.

#### **CJC Calibration Via The Modbus TCP/IP Interface:**

1. Write to the TC Break & CJC Configuration Register to turn CJC ON and set the break detection as required by your application.
2. Write to the appropriate Input Range Register to select the TC Type J range for the input channels adjacent to the CJC sensors (inputs 0, 2, and 4)—you will use these inputs to pass your CJC calibration signal.
3. Write 24106 (5E2AH) into the Calibration Access Register to remove write protection from the calibration registers.
4. Connect a Type J TC reference at 0°C (0.000mV) to inputs 0, 2, and 4 and allow the input to settle about 10 seconds.
5. Write a 16-bit value to the Tref Calibration Register with a set bit in the bit position that corresponds to the CJC channel to be calibrated (one channel at a time). If you are calibrating CJC0, you would write 0x0001 to the Tref Calibration Register. If calibrating CJC1, write 0x0002. If calibrating CJC2, write 0x0004. Note that the module will replace the calibration coefficients immediately and no reset is needed. Further, no response will be received and Modbus will timeout—this is normal, as it takes several seconds to process your calibration.

If calibration is successful, the input adjacent to the CJC will read 0.0°C  $\pm 0.1^\circ\text{C}$  after about 10 seconds (this is input 0, 2, or 4 for CJC 0, 1, or 2).

If calibration is not successful, the input adjacent to the CJC will read 1000.0°C (this is input 0, 2, or 4 for CJC 0, 1, or 2) and you must try to calibrate again. First, check that your input is a Type J TC, your module is warmed-up, your signal is 0°C (0.000mV), and you are at the correct input channel. Then retry calibration.

6. Repeat step 4-5 for the other CJC sensors.
7. When finished calibrating, write 0x0000 to the Calibration Access Register (Holding register 21) to replace write protection to the calibration registers and prevent miscalibration.

## **CJC Calibration**

*In order to calibrate CJC, the module ambient must be within 10°C to 40°C. Do not attempt to recalibrate CJC outside of, or near these end points, as this may negatively affect module accuracy.*

**CJC Calibration**

The following table gives the equivalent thermoelectric millivoltage for supported thermocouple types at various temperatures.


**Thermocouple millivoltage Versus Temperature**  
(From NIST National Institute of Standards and Technology TC Tables)

TEMP °C	Thermoelectric millivoltage (w/ Reference Junction at 0°C)						
	J	K	T	E	R	S	B
- 250	---	-6.404	-6.181	-9.719	---	---	---
- 200	-7.890	-5.891	-5.603	-8.824	---	---	---
- 150	-6.499	-4.912	-4.648	-7.279	---	---	---
- 100	-4.632	-3.553	-3.378	-5.237	---	---	---
- 50	-2.431	-1.889	-1.819	-2.787	---	---	---
0	0.000	0.000	0.000	0.000	0.000	0.000	0.000
+ 50	2.585	2.022	2.035	3.047	0.296	0.299	---
+ 100	5.268	4.095	4.277	6.317	0.647	0.645	---
+ 150	8.008	6.137	6.702	9.787	1.041	1.029	---
+ 200	10.777	8.137	9.286	13.419	1.468	1.440	---
+ 250	13.553	10.151	12.011	17.178	1.923	1.873	---
+ 300	16.325	12.207	14.860	21.033	2.400	2.323	---
+ 350	19.089	14.292	17.816	24.961	2.896	2.786	---
+ 400	21.846	16.395	20.869	28.943	3.407	3.260	---
+ 450	24.607	18.513	---	32.960	3.933	3.743	1.002
+ 500	27.388	20.640	---	36.999	4.471	4.234	1.241
+ 550	30.210	22.772	---	41.045	5.021	4.732	1.505
+ 600	33.096	24.902	---	45.085	5.582	5.237	1.791
+ 650	36.066	27.022	---	49.109	6.155	5.751	2.100
+ 700	39.130	29.128	---	53.110	6.741	6.274	2.430
+ 800	---	33.277	---	61.022	7.949	7.345	3.154
+ 900	---	37.325	---	68.783	9.203	8.448	3.957
+1000	---	41.269	---	76.358	10.503	9.585	4.833
+1200	---	48.828	---	---	13.224	11.947	6.783
+1400	---	---	---	---	16.035	14.368	8.952
+1600	---	---	---	---	18.842	16.771	11.257
+1700	---	---	---	---	20.215	17.942	12.462
+1750	---	---	---	---	20.878	18.504	13.008
+1800	---	---	---	---	---	---	13.585

The Offset Null buttons of the Test Page provide an additional tool to further increase temperature measurement accuracy between channels. Null is intended to be performed in the field, with a warm unit, and with the unit mounted as in the final application. It is an optional operation only for those applications that demand increased channel to channel convergence, beyond rated accuracy.

## WEB BROWSER

### Test Page - 0°C Offset Null (Optional)



There are three cold junction sensors on the 965EN-4006, and two on the 965EN-4004. One CJC sensor is used at each terminal block for each pair of TC channels. Because these sensors are located at different points on the circuit board, and at different temperatures, this difference is reflected in a measurement disparity between channels of the same unit. This is most apparent with the 6 channel TC units which displace the last two channels a greater distance from the first four. This disparity will vary with the position of the module, and whether units are tightly spaced with respect to one another. This tool allows you to null these differences between channels which will vary between applications.

**IMPORTANT:** This process works best if the ambient temperature of your module remains fairly consistent throughout operation. It will work at any rated temperature, but may generate additional error (temporary) where the ambient of the unit varies quickly. As such, it is best done in the ambient environment of your application and where the temperature remains stable. Do not perform this operation if your ambient changes quickly.

**Set Null** – Click this button to null the offset indicated with a 0°C input signal at the corresponding input for the TC type selected. Unit should be warm (1 hour minimum), in a stable ambient, and mounted as in the final application before nulling.

**Undo** – Click this button to remove any offset null at the channel indicated. Units from the factory do not include any null factors.

## WEB BROWSER

### Input-to-Input Offset Null Procedure

Follow this procedure to null any channel-to-channel offsets that may exist in your application for channels at 0°C:

#### 0°C Offset Null:

1. Mount the unit as required by your final application. If additional units are to be mounted next the unit, then these additional sources of heat must be included. The ambient should be stable and close to the ambient of your final application.
2. Turn on power to the unit(s) and allow the unit to warm up for 1 hour.
3. Write to the TC Break & CJC Configuration Register to turn CJC ON and set the break detection as required by your application. Optionally, you may use the web-browser Test Page controls to set TC break and enable CJC (easiest).
4. Write to the appropriate Input Range Register to select the TC Type for each channel that you will use to simulate an input signal at 0°C (you can pick any type, but may find it most convenient to pick the type you will be using in your application). Optionally, you may use the web-browser Test Page controls to change the input range (easiest). Note that you do not have to do this for every TC type.

Note the [Set Null] and [Undo] buttons next to each channel value of the Test Page. [Set Null] is used to install an offset to null the display of a non-zero value when the TC input signal is 0°C and CJC is turned ON. [Undo] removes any install null values. Units from the factory do not have offsets installed, as this offset will vary between applications

5. After unit has warmed up for an hour or more, connect your 0°C TC reference signal to each input channel and allow the input signal to settle at least 10 seconds. If the reading indicated does not read  $0.0^{\circ}\text{C} \pm 0.1^{\circ}\text{C}$ , then click the "Set Null" for that channel. Repeat this process for each channel.

**IMPORTANT:** If your 0°C reference TC signal is not accurate, you will effectively decrease the accuracy of your unit by clicking "Set Null". Make sure that you have accurately simulated a 0°C ice-point reference for your TC Type.

6. Repeat steps 1-5 for the input channels of any additional units of this application.

Note that if offset null is successful, your channels should continue to read  $0.0^{\circ}\text{C} \pm 0.1^{\circ}\text{C}$  for your simulated reference signal.

If you have any problems, or the accuracy of this operation has been compromised in any way, you can always click the Undo button to remove any installed offsets.

Upon power-up, the green RUN LED should light. A continuous blinking Run LED indicates “wink” ID mode. If the Run LED remains OFF and correct power has been applied, then either the internal power supply has failed or a fatal processor error (firmware) has occurred.

## TROUBLE-SHOOTING

<i>Green RUN LED does not light.</i>	Internal +3.3V power has failed.	Return module for repair.
<i>Continuous flashing green RUN LED.</i>	Module in “wink” mode.	Read Module Status register to verify “wink” status. Write 5555H to Wink Mode Toggle Register to toggle wink mode off/on.
<i>Cannot communicate.</i>	Power ON at the module?	Check power. Is green RUN LED ON?
	Connecting cable is not a crossover cable.  <i>TIP: To check cable type, hold both ends in same position and read the wire colors through the clear portion of the plug from left to right. If colors are arranged in the same order, you have a straight cable.</i>	This module’s ethernet port is wired MDI. You must use a crossover cable when connecting this module to your PC or another device also wired MDI. If you are connecting to an Ethernet switch or hub, then a direct cable is used.  <b>Note:</b> If your Link LED is ON, you have connected using the correct type of cable, but it could still be defective.
	Wrong IP Address	Change the IP address of the module or the PC so that both match. Try the default module address of 128.1.1.100. Try another PC NIC address.
<i>Many Communication Errors.</i>	Is cable segment longer than 100M?	Maximum distance between two nodes is limited to 100 meters with approved cable.
	Correct Cable?	Shielded CAT-5/5E cable or equivalent is recommended.
	Missing earth ground connection.	Connect earth ground to TB3-33 GND terminal adjacent to power terminal.
<i>Status LED always ON.</i>	Indicates a channel over-range condition.	Terminate unused input channels as break detection at an open channel will trigger over-range. Note that over-range indication may mask default mode indication via this LED.
<i>Cannot Browse Module.</i>	Your browser may be setup to use a proxy server for LAN communications.	Temporarily disable the use of a proxy server by your browser (see procedure of next page).

*If your problem still exists after checking your wiring and reviewing this information, or if other evidence points to another problem with the unit, an effective and convenient fault diagnosis method is to exchange the module with a known good unit. Acromag’s Application Engineers can provide further technical assistance if required. Complete repair services are also available from Acromag.*

## TROUBLE-SHOOTING

Please refer Acromag Application Note 8500-734 for help in setting up network communication with your module (located on the CDROM shipped with your module or via download from our web site at [www.acromag.com](http://www.acromag.com)). This document gives details for changing your PC's TCP/IP configuration in order to communicate with your module (see TCP/IP Properties of Network Configuration in Windows).

### Trouble Browsing Your Module?

If you have carefully followed this procedure and you still cannot browse your module, you may have the web browser of your laptop or PC setup to use a proxy server when browsing the web. If you are using Internet Explorer, Refer to the "Tools" pulldown menu, select "Internet options...", click the "Connections" tab, then click the "LAN Settings" button. Locate the Proxy server information and uncheck the box next to the statement "Use a proxy server for your LAN". Then click [OK] to return to the "Connections" screen, and click [OK] again to save your settings.

You should now be able to use Internet Explorer to browse the module as required. However, to later restore your PC's connection to your company network, you may have to re-enable the use of a proxy server for your LAN.

### Getting Out Of Trouble

There is no built-in error detection to prevent you from writing invalid values to a configuration register. As such, if you inadvertently write an invalid value to an internal register, you could cause the module to become inoperable under certain conditions. If this happens, in order to regain control of the module, the module can either be re-downloaded at the factory, or you can try restoring the module to its initial configuration by following this procedure:

*So, your module's "gone wild", follow this procedure to restore it to its initial configuration and regain control.*

#### **Procedure For Restoring any 9xxEN Module to its Initial Configuration**

1. While module power is OFF, press and hold the front-panel toggle switch in the default (DFT left) position.
2. While continuing to hold the toggle switch in the default position, apply power to the module.
3. After a few seconds, the Status LED will begin to blink quickly and you can release the default switch at this point. The module will continue to boot itself as it normally does. That is, the green RUN LED will blink for 1-10 seconds as the unit acquires its address, then remain ON for normal operation.
4. If the STATUS LED fails to blink rapidly after a few seconds and the RUN LED just blinks for a few moments as it normally does, then reinitializing the module has failed and you should try it again. This time, make sure that the DFT switch is completely depressed and held while powering the unit. Also make sure that you are pressing the DFT toggle in the DFT direction (left), rather than the RST direction (right).



## TECHNICAL REFERENCE


- **Safety Agency Approvals** – CE, UL, & cUL listed, plus Class I; Division 2; Groups A, B, C, D approval.
- **Fully Isolated** – Input channels (as a group), network, and power are all isolated from each other for safety and increased noise immunity.
- **Modbus TCP/IP Protocol Support** – Supports up to 10 master sockets (maximum number is user-selectable) using port number 502 (Modbus TCP/IP Default).
- **I/O Mapping (i2o) Feature** – Allows the analog inputs of these models to map their values to the analog outputs of 972/973EN-4006 modules on the network.
- **Built-In Web Pages** - Allows unit to optionally be configured, controlled, calibrated, and monitored via a standard web browser over ethernet.
- **Convenient “Wink” ID Mode Support** – Blinks green Run LED in wink mode as a visual tool to help identify specific remote units on a network.
- **Fully Independent w/ Direct I/O Connection** – Self-contained with no special bus couplers, power supply, or rack mount required to operate.
- **Isolated Network Interface** – Immune to noise & can operate over long distances. Allows many modules to network together.
- **Network Port is Transient Protected** – Shielded RJ45 port includes transient protection from ESD, EFT, and other transients.
- **10Base-T and 100Base-TX Support** – Per IEEE 802.3/802.3u.
- **Auto-Negotiated 10/100Mbps, Half or Full Duplex.**
- **Flexible DC Millivolt or Thermocouple Inputs** - Accepts either DC millivolt, or thermocouple input signals, with linearization, lead break detection, and TC reference junction compensation included.
- **Range Variability** – The first 3 channels must share the same range, but this can be different than the range of the last 3 channels (965EN-4006), or the fourth channel (965EN-4004).
- **Precise High-Resolution A/D Conversion** – Modules use high-resolution, low noise, sigma-delta, analog-to-digital conversion for high accuracy and reliability.
- **Plug-In Terminal Blocks & DIN-Rail Mount** - Make mounting, removal, and replacement easy.
- **Nonvolatile Reprogrammable Memory** – Allows the functionality of this device to be reliably reprogrammed thousands of times.
- **Operation/Diagnostic LED Indicators Aide Troubleshooting** – Yellow ACT LED indicates port activity (busy). Green LNK LED indicates link (auto-negotiation complete and connection established). Green RUN LED indicates power or blinks in wink ID mode. Yellow ST LED indicates the default communication mode (flashing) and stays ON if an input is over or under range.
- **Internal Watchdog** - A hardware watchdog timer is built into the microcontroller that causes it to initiate a self reset if the controller ever “locks up” or fails to return from an operation in a timely manner.
- **Wide-Range DC-Power** – Wide range diode-coupled for use with redundant supplies, and/or battery back-up.
- **Hardened For Harsh Environments** - For protection from RFI, EMI, ESD, EFT, & surges. Has low radiated emissions per CE requirements.
- **Wide Ambient Operation** – Reliable over a wide temperature range.

## KEY FEATURES

### HOW IT WORKS

These input modules will interface with up to four or six DC voltage or thermocouple input channels according to the model number, and provide an isolated 10/100 Ethernet interface for configuration, monitoring, and control of the input module. A multiplexer is used to connect each input to an A/D converter (2 A/D channels serve up to 3 channels each). Separate temperature sensors (one per channel pair/terminal block) are used to accomplish thermocouple cold junction compensation and are multiplexed to a third A/D channel. The A/D converter then applies appropriate gain to the signals, performs analog-to-digital conversion, and digitally filters the signals. The A/D converter also switches the lead pullups/pulldowns to facilitate upscale or downscale thermocouple break detection. The digitized A/D signal is then transmitted serially to a microcontroller. The microcontroller completes the transfer function according to the input type and its embedded program. Configuration and calibration parameters are stored in non-volatile memory integrated within the microcontroller. The I/O terminals and the Ethernet port terminals also include transient suppression. A dedicated Ethernet controller handles Ethernet communication. A wide input switching regulator (isolated flyback) provides isolated power to the I/O circuits and the Ethernet controller. Refer to the simplified schematic shown below to help gain a better understanding of the circuit.

Note that input types may vary between channel groups—channel group 0, 1, and 2 may be configured differently from channel group 3, 4, and 5. Inputs are not isolated channel-to-channel, except for small common mode voltage differences in the range of ±4V.




TCP/IP is the foundation for the World Wide Web and refers to Transmission Control Protocol and Internet Protocol. TCP/IP allows blocks of binary data to be exchanged between computers. The primary function of TCP is to ensure that all packets of data are received correctly. IP makes sure that messages are correctly addressed and routed. Note that the TCP/IP combination does not define what the data means or how the data is to be interpreted, it is merely a *transport protocol*.

Modbus is an *application protocol*. It defines rules for organizing and interpreting data and is essentially a messaging structure that is independent of the underlying physical layer. It is freely available and accessible to anyone, easy to understand, and widely supported by many manufacturers.

Modbus TCP/IP uses TCP/IP and Ethernet to carry the data of the Modbus message structure between devices. That is, Modbus TCP/IP combines a physical network (Ethernet), with a networking standard (TCP/IP), and a standard method of representing data (Modbus). A Modbus TCP/IP message is simply a Modbus communication encapsulated in an Ethernet TCP/IP wrapper.

In practice, Modbus TCP embeds a Modbus data frame into a TCP frame, without the Modbus checksum, as shown in the following diagram. The Modbus checksum is not used, as the standard ethernet TCP/IP link layer checksum methods are instead used to guaranty data integrity.



Note that the Modbus address field is referred to as the *Unit Identifier* in Modbus TCP. In a typical slave application, the Unit ID is ignored and just echoed back in the response.

The operation of the 965EN industrial Ethernet modules are very similar to Acromag's 932MB ModBus modules. The operation over Ethernet is essentially transparent to the Modbus register/command structure. If you are already familiar with Modbus or with Acromag Series 900MB modules, then you are already familiar with the operation of the 965EN modules.

A host is any device on any network. On TCP/IP networks, each host has one or more unique IP addresses. This module connected to an ethernet network is a host.

An IP Address is a unique identification number for any host (this module) on any TCP/IP network (including the internet). The IP address is made up of four octets (8 bits), each octet having a value between 0-255 (00H-FFH). The IP address is comprised of two parts: the network address (first part) and the host address (last part). The number of octets of the four total that belong to the network address depend on the Class definition (see below).

## ABOUT MODBUS TCP/IP

You can find more information on Modbus TCP/IP by visiting our web site and down-loading whitepaper 8500-765, *Introduction To Modbus TCP/IP*.

## IP Addressing

## IP Addressing

A *Static IP Address* is as the name implies—static. That is, it is a unique IP Address that is assigned by a service provider and never changes.

A *Dynamic IP Address* is an address that is temporarily assigned to a user by a service provider each time a user connects.

A *Subnet* is a contiguous string of IP addresses. The first IP address in a subnet is used to identify the subnet and usually addresses the server for the subnet. The last IP address in a subnet is always used as a broadcast address and anything sent to the last IP address of a subnet is sent to every host on that subnet.

Subnets are further broken down into three size classes based on the 4 octets that make up the IP address. A Class A subnet is any subnet that shares the first octet of the IP address. The remaining 3 octets of a Class A subnet will define up to 16,777,214 possible IP addresses ( $2^{24} - 2$ ). A Class B subnet shares the first two octets of an IP address (providing  $2^{16} - 2$ , or 65534 possible IP addresses). Class C subnets share the first 3 octets of an IP address, giving 254 possible IP addresses. Recall that the first and last IP addresses are always used as a network number and broadcast address respectively, and this is why we subtract 2 from the total possible unique addresses that are defined via the remaining octet(s).

For our example, the default IP address of this module is 128.1.1.100. If we assume that this is a Class C network address (based on the default Class C subnet mask of 255.255.255.0), then the first three numbers represent this Class C network at address 128.1.1.0, the last number identifies a unique host/node on this network (node 100) at address 128.1.1.100.

A *Subnet Mask* is used to determine which subnet an IP address belongs to. The use of a subnet mask allows the network administrator to further divide the host part of this address into two or more subnets. The subnet mask flags the network address portion of the IP address, plus the bits of the host part that are used for identifying the sub-network. By convention, the bits of the mask that correspond to the sub-network address are all set to 1's (it would also work if the bits were set exactly as in the network address). It's called a mask because it can be used to identify the unique subnet to which an IP address belongs to by performing a bitwise AND operation between the mask itself, and the IP address, with the result being the sub-network address, and the remaining bits the host or node address.

*Note that the first node address (0) and node 10 are typically reserved for servers and should not be used. The last node (255) is a broadcast address. Node 100 is the default address of this module. Use of these node addresses for any other purpose may yield poor performance.*

For our Example, if we wish to further divide this network into 14 subnets, then the first 4 bits of the host address will be required to identify the subnetwork (0110), then we would use "11111111.11111111.11111111.11110000" as our subnet mask. This would effectively subdivide our Class C network into 14 subnetworks of up to 14 possible nodes each.

With respect to the default settings of this module:

Subnet Mask 255.255.255.0 (11111111.11111111.11111111.00000000)  
 IP Address: 128.1.1.100 (10000000.00000001.00000001.01100100)  
 Subnet Address: 128.1.1.0 (1000000.00000001.00000001.00000000)

Subnetwork address 128.1.1.0 has 254 possible unique node addresses. We are using node 100 of 254 possible for our module.

DHCP refers to Dynamic Host Configuration Protocol and is a method used to dynamically assign temporary numeric IP addresses as required. A DHCP server maintains a pool of shared IP addresses which are recycled. When a DHCP device wants to use a TCP/IP application, it must request an IP address from the DHCP server. The DHCP server will check the shared supply, and if all addresses are in use, the server will send a busy signal to the client which tells it to try again later. Static addresses will ensure a connection every time, but dynamic addresses do not.

**Dynamic Host Configuration Protocol (DHCP)**

DNS refers to the Domain Name System or Domain Name Server and refers to the system used to associate an alphanumeric character string with a numeric IP address. The DNS is actually a distributed database of domain names and corresponding IP addresses. These servers contain information on some segment of the domain name space and make this information available to clients called *resolvers*. For example, the DNS allows us to use "Acromag.com" as an IP address rather than a complicated number string.

**Domain Name System (DNS)**

Modbus registers are organized into reference types identified by the leading number of the reference address:

**MODBUS REGISTERS**

Reference	Description
0xxxx	<u>Read/Write Discrete Outputs or Coils.</u> A 0x reference address is used to drive output data to a digital output channel.
1xxxx	<u>Read Discrete Inputs.</u> The ON/OFF status of a 1x reference address is controlled by the corresponding digital input channel.
3xxxx	<u>Read Input Registers.</u> A 3x reference register contains a 16-bit number received from an external source—e.g. an analog signal.
4xxxx	<u>Read/Write Output or Holding Registers.</u> A 4x register is used to store 16-bits of numerical data (binary or decimal), or to send the data from the CPU to an output channel.

*The "x" following the leading character represents a four-digit address location in user data memory.*

*The leading character is generally implied by the function code and omitted from the address specifier for a given function. The leading character also identifies the I/O data type.*

**Note:** The ON/OFF state of discrete inputs and outputs is represented by a 1 or 0 value assigned to an individual bit in a 16-bit data word. This is sixteen 0x or 1x references per data word. With respect to mapping, the LSB of the word maps to the lowest numbered channel of a group and channel numbers increase sequentially as you move towards the MSB. Unused bit positions are set to zero.

All I/O values are accessed via the 16-bit Input or Holding Registers given in the Register Map. Input registers contain read-only information. For example, the current input value read from a channel, or the states of a group of digital inputs. Holding registers contain read/write information that may be configuration data or output data. For example, the high limit value of an alarm operating at an input, or an output value for an output channel.

**Register Functions**

Each module has a default factory configuration as noted in the SPECIFICATIONS section. Your application will likely differ from the default configuration and the module will need to be reconfigured. You may reconfigure this module by issuing the appropriate Modbus functions to Register Map registers, as required by your application. You may also use a standard web browser to access the built-in web pages of the module to perform basic operations.

## Register Functions

**IMPORTANT:** When using your own software to manipulate the module, please note that the maximum query through the Modbus TCP interface is only 50 registers, due to the maximum buffer size limitations of the TCP/IP stack. As such, you can only request data from 50 registers at one time for commands that access multiple registers. For example, the Read Holding Registers command may only retrieve the contents of registers 40001 to 40051 in one read.

Below is a subset of standard Modbus functions that are supported by this module along with the reference register addresses that the function operates on. Use these functions to access these registers as outlined in the Register Map for sending and retrieving data.

The following Modbus functions operate on register map registers to monitor, configure, and control module I/O:

CODE	FUNCTION	REFERENCE
01 (01H)	Read Coil (Output) Status	0xxxx
02 (02H)	Read Input Status	1xxxx
03 (03H)	Read Holding Registers	4xxxx
04 (04H)	Read Input Registers	3xxxx
05 (05H)	Force Single Coil (Output)	0xxxx
06 (06H)	Preset Single Register	4xxxx
15 (0FH)	Force Multiple Coils (Outputs)	0xxxx
16 (10H)	Preset Multiple Registers	4xxxx
17 (11H)	Report Slave ID (See Below)	Hidden

If an unsupported function code is sent to a module, exception code 01 (Illegal Function) will be returned in the response. If a holding register is written with an invalid value, exception code 03 (Illegal Data Value) will be returned in the response message. You may refer to the Modbus specification for a complete list of possible error codes.

### 965EN-4006 Report Slave ID Example Response

FIELD	DESCRIPTION
Unit ID	Echo Unit ID Sent In Query
Function Code	11
Byte Count	42
Slave ID (Model No.)	04=965EN-4004 (4 mV/TC Input) 05=965EN-4006 (6 mV/TC Input)
Run Indicator Status	FFH (ON)
Firmware Number String (Additional Data Field)	41 43 52 4F 4D 41 47 2C 39 33 30 30 2D <b>31 32 33</b> 2C 39 <b>36 35</b> 45 4E 2D <b>34 30 30 36</b> 2C 30 31 32 33 34 35 41 2C 30 31 32 33 34 35 ("ACROMAG,9300- <b>123,965EN-4006</b> ,serial number&rev,six-byteMACID")

For detailed information on Modbus, feel free to download technical reference 8500-648, "Introduction To Modbus" at [www.acromag.com](http://www.acromag.com). For more information on Modbus TCP/IP, download whitepaper 8500-765, "Introduction To Modbus TCP/IP".

## Register Mirroring

For your convenience, 9xxEN Ethernet modules mirror the contents and operation of registers 0xxxx, 1xxxx, & 3xxxx (as applicable) into holding register space for systems and controllers that cannot directly access registers 0xxxx, 1xxxx, & 3xxxx.

All Modbus registers of this model can now be written to, or read from, using either the standard methods described in the Modbus specification, or through mapping (mirroring) to the Holding Registers. The registers are mapped as follows and specifics follow the mapping:

0xxxx Coil Registers are mapped to 42xxx Holding Registers  
 1xxxx Input Status Registers are mapped to 41xxx Holding Registers  
 3xxxx Input Registers are mapped to 43xxx Holding Registers

**Register Mirroring**

For 3xxxx Input Registers, the format of the registers are identical and you only need to offset your address by 43000. For example: if you want to read Input Register 1 through the Holding Registers, you would use the "Read Holding Registers" function with an address of 43001.

For the 1xxxx Input Status Registers (where supported), the return data is reformatted to match the Holding Register format. For example: if you request the Input Status for 12 digital inputs, instead of getting 2 bytes returned with the first 12 bits representing the 12 digital inputs, you will get 12 separate words, each set to either 0000H (OFF), or FFFFH (ON).

For the 0xxxx Coil Registers (where supported), reads are handled in the same way as the 1xxxx Input Status Registers. You can also write to the coil registers by using the "Preset Single Register" function with an address offset of 42000. Setting the data to 0000H will turn the coil OFF, while setting the data to FF00H will turn the coil ON. Writing to multiple coils is not supported via register mirroring, you must use the "Write Multiple Coils" function for that.

Note that with respect to Acromag 9xxMB Modbus RTU modules, only 3xxxx Input Registers are mirrored into 4xxxx space, not Coil or Input Status registers as noted here for 9xxEN models.

I/O values for Series 900EN modules are represented by the following simple data types for temperature, percentage, and discrete on/off.

**Data Types**

**Summary Of Data Types Used By 900MB/900EN Modules**

<b>Data Types</b>	<b>Description</b>
<b>Normalized Data Count</b>  (This Model, ±1V, ±100mV ranges)	A 16-bit signed integer value is used to represent ±20000 counts for bipolar input ranges and 0-20000 counts for unipolar input ranges. For example, -1V, 0V and +1V are represented by integer values -20000, 0, and 20000 for bipolar devices, respectively.
<b>Temperature</b> (This Model, TC inputs)	A 16-bit signed integer value with resolution of 0.1°C/lb represents the range of a TC type measured in degrees C. For example, a JTC type has a range of -210 to 760C, which read -2100 to 7600 counts within the data register respectively.
Discrete	A discrete value is generally indicated by a single bit of a 16-bit word. The bit number/position typically corresponds to the discrete channel number for this model. Unless otherwise defined for outputs, a 1 bit means the corresponding output is closed or ON, a 0 bit means the output is open or OFF. For inputs, a value of 1 means the input is ON (Active low near 0V), while a value of 0 specifies the input is OFF or in its high state

## Register Map

### Model 965EN-4006 Model 965EN-4004

The following table outlines the register map for the Model 965EN-4004 and 965EN-4006 network input modules. The Modbus functions operate on these registers using the data types noted above (except for the Reset Slave and Report Slave ID functions). Unless otherwise noted, Holding Register values are maintained in flash and are non-volatile.

Ref	Addr.	Description	Data Type/Format
<b>Input Registers (3x References, Read-Only)</b>			
30001	0000	Module Status	Bit 15: 0 (Not Used) Bit 14: Wink Mode Flag 1 = Wink Mode (Blinks Run LED for ID) 0 = Normal Operation (See Wink Module Register) Bit 13: Default Mode Flag 1 = Default Mode Indicator 0 = Not Default Mode Bits 12-0: (Not Used)
30002	0001	Input Range (CH 0,1,2 )	Bits 15-4: 0 (Not Used) Bits 3,2,1,0: Input Range 0000 J TC (°C) 0001 K TC (°C) 0010 T TC (°C) 0011 R TC (°C) 0100 S TC (°C) 0101 E TC (°C) 0110 B TC (°C) 0111 N TC (°C) 1000 ±100mV DC 1001 ±1V DC 1010-1111 Reserved
30003	0002	Input Range (CH 3,4,5 )	Format is same as Above.
30004	0003	CJC Control (CH 0, 1, 2)	Bits 15-1: 0 (Not Used) Bit 0: 0=CJC ON, 1=CJC OFF
30005	0004	CJC Control (CH 3, 4, 5)	Bits 15-1: 0 (Not Used) Bit 0: 0=CJC ON, 1=CJC OFF
30006	0005	TC Break Detection	Bits 15-1: 0 (Not Used) Bit 0: 0=Upscale, 1=Downscale
30007	0006	CH00 Status	Bits 15-2: 0 (Not Used) Bits 1,0: Input Signal Status 00 In Range 01 Over-Range 10 Under-Range 11 Not Used
30008	0007	CH01 Status	Same Format as CH00 (See Above)
30009	0008	CH02 Status	Same Format as CH00 (See Above)
30010	0009	CH03 Status	Same Format as CH00 (See Above)
30011	000A	CH04 Status (965EN-4006)	Same Format as CH00 (See Above)
30012	000B	CH05 Status (965EN-4006)	Same Format as CH00 (See Above)

**Note (TC Break):** TC input values are represented via 16-bit signed integers with a resolution of 0.1°C/lb and a possible range of -3276.8°C to +3276.7°C. With 16-bit signed integers, a count of 0-7FFFH is a positive number, while 8000-FFFFH is a negative number. The downscale (break) detent is 32768 for all TC types. However, the upscale break over-range count is trimmed to a reasonable range value according to the TC type as follows: 12895 (J), 20068 (K), 6820 (T), 31190 (R), 32767 (S), 20205 (E), 22824 (B), and 21002 (N).



Ref	Addr.	Description	Data Type/Format
<b>Input Registers (3x References, Read-Only)</b>			
30013	000C	CH00 Value	±20000 (Voltage input range) or Temperature (°C)
30014	000D	CH01 Value	±20000 (Voltage input range) or Temperature (°C)
30015	000E	CH02 Value	±20000 (Voltage input range) or Temperature (°C)
30016	000F	CH03 Value	±20000 (Voltage input range) or Temperature (°C)
30017	0010	CH04 Value (965EN-4006)	±20000 (Voltage input range) or Temperature (°C)
30018	0011	CH05 Value (965EN-4006)	±20000 (Voltage input range) or Temperature (°C)
30019	0012	Temp Ref 0 Value (CJC0)	Temperature (°C)
30020	0013	Temp Ref 1 Value (CJC1)	Temperature (°C)
30021	0014	Temp Ref 2 Value (CJC2) (965EN-4006)	Temperature (°C)
30028	001B	CJC0 Count	Raw A/D Count Value
30029	001C	CJC1 Count	Raw A/D Count Value
30030	001D	CJC2 Count (965EN-4006)	Raw A/D Count Value
<b>Holding Registers (4x References, Read/Write)</b>			
40001	0000	Input Range (CH 0,1,2 )	Bits 15-4: 0 (Not Used) Bits 3,2,1,0: Input Range 0-9 0000 0 - J TC (°C) 0001 1 - K TC (°C) 0010 2 - T TC (°C) 0011 3 - R TC (°C) 0100 4 - S TC (°C) 0101 5 - E TC (°C) 0110 6 - B TC (°C) 0111 7 - N TC (°C) 1000 8 - ±100mV DC 1001 9 - ±1V DC 1010-1111 Reserved
40002	0001	Input Range (CH 3,4,5 )	Format is same as Above.
40003	0002	CJC Control (CH 0, 1, 2)	Bits 15-1: 0 (Not Used) Bit 0: 0=CJC ON, 1=CJC OFF
40004	0003	CJC Control (CH 3, 4, 5)	Bits 15-1: 0 (Not Used) Bit 0: 0=CJC ON, 1=CJC OFF

## Register Map

**Model 965EN-4006**  
**Model 965EN-4004**

**Note:** Changes to Holding Registers take effect immediately.

## Register Map

Model 965EN-4006  
Model 965EN-4004

Ref	Addr.	Description	Data Type/Format
<b>Holding Registers (4x References, Read/Write)</b>			
40005	0004	TC Break (applies to all inputs)	<u>Bits 15-1:</u> 0 (Not Used) <u>Bit 0:</u> 0=Upscale (Default); 1=Downscale
40006	0005	Reserved	Do Not Use
40007	0006	Reserved	Do Not Use
40008	0007	Reserved	Do Not Use
40009	0008	Reserved	Do Not Use
40010	0009	Reserved	Do Not Use
40011	000A	Reserved	Do Not Use
40012	000B	Reserved	Do Not Use
40013	000C	Reserved	Do Not Use
40014	000D	Reserved	Do Not Use
40015	000E	Reserved	Do Not Use
40016	000F	Reserved	Do Not Use
40017	0010	Reserved	Do Not Use
40018	0011	Reserved	Do Not Use
40019	0012	Reserved	Do Not Use
40020	0013	Reserved	Do Not Use
40021	0014	Calibration Access  And  Wink Mode Toggle  And  Restore Factory Calibration  And  <b>Factory Use Only</b>	<p>Writing 24106 (5E2AH) here immediately removes write protection from the calibration registers that follow. All other values apply write protection to the calibration registers (except 21845, 44718, and 43981--See Below).</p> <p>Writing 21845 (5555H) to this register will cause the module to "Wink" its Run LED. Writing this value a second time will stop "Wink" (Toggles Wink ON/OFF).</p> <p>Writing 44718 (AEA EH) will cause the module to restore its factory calibration. This can only be done after "Save Factory Calibration" has been done at the factory.</p> <p>Writing 43981 (ABCDH) is reserved for factory use. <b>This should not be performed by anyone else or operation will be degraded.</b></p> <p>This register always reads back 0. After a reset, this register is set back to 0 (write protection enabled and no wink).</p> <p><b>This register is not maintained in flash.</b></p>

Ref	Addr.	Description	Data Type/Format
<b>Holding Registers (4x References, Read/Write)</b>			
40022	0015	CH0 Cal Hi Range 0	Raw A/D Count Value J Type TC
40023	0016	CH0 Cal Lo Range 0	Raw A/D Count Value J Type TC
40024	0017	CH0 Cal Hi Range 1	Raw A/D Count Value K Type TC
40025	0018	CH0 Cal Lo Range 1	Raw A/D Count Value K Type TC
40026	0019	CH0 Cal Hi Range 2	Raw A/D Count Value T Type TC
40027	001A	CH0 Cal Lo Range 2	Raw A/D Count Value T Type TC
40028	001B	CH0 Cal Hi Range 3	Raw A/D Count Value R Type TC
40029	001C	CH0 Cal Lo Range 3	Raw A/D Count Value R Type TC
40030	001D	CH0 Cal Hi Range 4	Raw A/D Count Value S Type TC
40031	001E	CH0 Cal Lo Range 4	Raw A/D Count Value S Type TC
40032	001F	CH0 Cal Hi Range 5	Raw A/D Count Value E Type TC
40033	0020	CH0 Cal Lo Range 5	Raw A/D Count Value E Type TC
40034	0021	CH0 Cal Hi Range 6	Raw A/D Count Value B Type TC
40035	0022	CH0 Cal Lo Range 6	Raw A/D Count Value B Type TC
40036	0023	CH0 Cal Hi Range 7	Raw A/D Count Value N Type TC
40037	0024	CH0 Cal Lo Range 7	Raw A/D Count Value N Type TC
40038	0025	CH0 Cal Hi Range 8	Raw A/D Count Value ±100mVDC
40039	0026	CH0 Cal Lo Range 8	Raw A/D Count Value ±100mVDC
40040	0027	CH0 Cal Hi Range 9	Raw A/D Count Value ±1VDC
40041	0028	CH0 Cal Lo Range 9	Raw A/D Count Value ±1VDC
40042	0029	CH1 Cal Hi Range 0	Raw A/D Count Value J Type TC
40043	002A	CH1 Cal Lo Range 0	Raw A/D Count Value J Type TC
40044	002B	CH1 Cal Hi Range 1	Raw A/D Count Value K Type TC
40045	002C	CH1 Cal Lo Range 1	Raw A/D Count Value K Type TC
40046	002D	CH1 Cal Hi Range 2	Raw A/D Count Value T Type TC
40047	002E	CH1 Cal Lo Range 2	Raw A/D Count Value T Type TC

## Register Map

**Model 965EN-4006**

**Model 965EN-4004**

*Shaded 4xxxx register entries are Read Only*

## Register Map

**Model 965EN-4006**

**Model 965EN-4004**

*Shaded 4xxxx register entries are Read-Only.*

Ref	Addr.	Description	Data Type/Format
<b>Holding Registers (4x References, Read/Write)</b>			
40048	002F	CH1 Cal Hi Range 3	Raw A/D Count Value R Type TC
40049	0030	CH1 Cal Lo Range 3	Raw A/D Count Value R Type TC
40050	0031	CH1 Cal Hi Range 4	Raw A/D Count Value S Type TC
40051	0032	CH1 Cal Lo Range 4	Raw A/D Count Value S Type TC
40052	0033	CH1 Cal Hi Range 5	Raw A/D Count Value E Type TC
40053	0034	CH1 Cal Lo Range 5	Raw A/D Count Value E Type TC
40054	0035	CH1 Cal Hi Range 6	Raw A/D Count Value B Type TC
40055	0036	CH1 Cal Lo Range 6	Raw A/D Count Value B Type TC
40056	0037	CH1 Cal Hi Range 7	Raw A/D Count Value N Type TC
40057	0038	CH1 Cal Lo Range 7	Raw A/D Count Value N Type TC
40058	0039	CH1 Cal Hi Range 8	Raw A/D Count Value $\pm 100\text{mVDC}$
40059	003A	CH1 Cal Lo Range 8	Raw A/D Count Value $\pm 100\text{mVDC}$
40060	003B	CH1 Cal Hi Range 9	Raw A/D Count Value $\pm 1\text{VDC}$
40061	003C	CH1 Cal Lo Range 9	Raw A/D Count Value $\pm 1\text{VDC}$
40062	003D	CH2 Cal Hi Range 0	Raw A/D Count Value J Type TC
40063	003E	CH2 Cal Lo Range 0	Raw A/D Count Value J Type TC
40064	003F	CH2 Cal Hi Range 1	Raw A/D Count Value K Type TC
40065	0040	CH2 Cal Lo Range 1	Raw A/D Count Value K Type TC
40066	0041	CH2 Cal Hi Range 2	Raw A/D Count Value T Type TC
40067	0042	CH2 Cal Lo Range 2	Raw A/D Count Value T Type TC
40068	0043	CH2 Cal Hi Range 3	Raw A/D Count Value R Type TC
40069	0044	CH2 Cal Lo Range 3	Raw A/D Count Value R Type TC
40070	0045	CH2 Cal Hi Range 4	Raw A/D Count Value S Type TC
40071	0046	CH2 Cal Lo Range 4	Raw A/D Count Value S Type TC
40072	0047	CH2 Cal Hi Range 5	Raw A/D Count Value E Type TC
40073	0048	CH2 Cal Lo Range 5	Raw A/D Count Value E Type TC

Ref	Addr.	Description	Data Type/Format
<b>Holding Registers (4x References, Read/Write)</b>			
40074	0049	CH2 Cal Hi Range 6	Raw A/D Count Value B Type TC
40075	004A	CH2 Cal Lo Range 6	Raw A/D Count Value B Type TC
40076	004B	CH2 Cal Hi Range 7	Raw A/D Count Value N Type TC
40077	004C	CH2 Cal Lo Range 7	Raw A/D Count Value N Type TC
40078	004D	CH2 Cal Hi Range 8	Raw A/D Count Value $\pm 100\text{mVDC}$
40079	004E	CH2 Cal Lo Range 8	Raw A/D Count Value $\pm 100\text{mVDC}$
40080	004F	CH2 Cal Hi Range 9	Raw A/D Count Value $\pm 1\text{VDC}$
40081	0050	CH2 Cal Lo Range 9	Raw A/D Count Value $\pm 1\text{VDC}$
40082	0051	CH3 Cal Hi Range 0	Raw A/D Count Value J Type TC
40083	0052	CH3 Cal Lo Range 0	Raw A/D Count Value J Type TC
40084	0053	CH3 Cal Hi Range 1	Raw A/D Count Value K Type TC
40085	0054	CH3 Cal Lo Range 1	Raw A/D Count Value K Type TC
40086	0055	CH3 Cal Hi Range 2	Raw A/D Count Value T Type TC
40087	0056	CH3 Cal Lo Range 2	Raw A/D Count Value T Type TC
40088	0057	CH3 Cal Hi Range 3	Raw A/D Count Value R Type TC
40089	0058	CH3 Cal Lo Range 3	Raw A/D Count Value R Type TC
40090	0059	CH3 Cal Hi Range 4	Raw A/D Count Value S Type TC
40091	005A	CH3 Cal Lo Range 4	Raw A/D Count Value S Type TC
40092	005B	CH3 Cal Hi Range 5	Raw A/D Count Value E Type TC
40093	005C	CH3 Cal Lo Range 5	Raw A/D Count Value E Type TC
40094	005D	CH3 Cal Hi Range 6	Raw A/D Count Value B Type TC
40095	005E	CH3 Cal Lo Range 6	Raw A/D Count Value B Type TC
40096	005F	CH3 Cal Hi Range 7	Raw A/D Count Value N Type TC
40097	0060	CH3 Cal Lo Range 7	Raw A/D Count Value N Type TC
40098	0061	CH3 Cal Hi Range 8	Raw A/D Count Value $\pm 100\text{mVDC}$
40099	0062	CH3 Cal Lo Range 8	Raw A/D Count Value $\pm 100\text{mVDC}$

## Register Map

**Model 965EN-4006**

**Model 965EN-4004**

*Shaded 4xxxx register entries are Read-Only.*

## Register Map

### Model 965EN-4006 Model 965EN-4004

Shaded 4xxxx register entries  
are Read-Only.

Ref	Addr.	Description	Data Type/Format
<b>Holding Registers (4x References, Read/Write)</b>			
40100	0063	CH3 Cal Hi Range 9	Raw A/D Count Value $\pm 1$ VDC
40101	0064	CH3 Cal Lo Range 9	Raw A/D Count Value $\pm 1$ VDC
40102	0065	CH4 Cal Hi Range 0	Raw A/D Count Value J Type TC (Model 965EN-4006 Only)
40103	0066	CH4 Cal Lo Range 0	Raw A/D Count Value J Type TC (Model 965EN-4006 Only)
40104	0067	CH4 Cal Hi Range 1	Raw A/D Count Value K Type TC (Model 965EN-4006 Only)
40105	0068	CH4 Cal Lo Range 1	Raw A/D Count Value K Type TC (Model 965EN-4006 Only)
40106	0069	CH4 Cal Hi Range 2	Raw A/D Count Value T Type TC (Model 965EN-4006 Only)
40107	006A	CH4 Cal Lo Range 2	Raw A/D Count Value T Type TC (Model 965EN-4006 Only)
40108	006B	CH4 Cal Hi Range 3	Raw A/D Count Value R Type TC (Model 965EN-4006 Only)
40109	006C	CH4 Cal Lo Range 3	Raw A/D Count Value R Type TC (Model 965EN-4006 Only)
40110	006D	CH4 Cal Hi Range 4	Raw A/D Count Value S Type TC (Model 965EN-4006 Only)
40111	006E	CH4 Cal Lo Range 4	Raw A/D Count Value S Type TC (Model 965EN-4006 Only)
40112	006F	CH4 Cal Hi Range 5	Raw A/D Count Value E Type TC (Model 965EN-4006 Only)
40113	0070	CH4 Cal Lo Range 5	Raw A/D Count Value E Type TC (Model 965EN-4006 Only)
40114	0071	CH4 Cal Hi Range 6	Raw A/D Count Value B Type TC (Model 965EN-4006 Only)
40115	0072	CH4 Cal Lo Range 6	Raw A/D Count Value B Type TC (Model 965EN-4006 Only)
40116	0073	CH4 Cal Hi Range 7	Raw A/D Count Value N Type TC (Model 965EN-4006 Only)
40117	0074	CH4 Cal Lo Range 7	Raw A/D Count Value N Type TC (Model 965EN-4006 Only)
40118	0075	CH4 Cal Hi Range 8	Raw A/D Count Value $\pm 100$ mVDC (Model 965EN-4006 Only)
40119	0076	CH4 Cal Lo Range 8	Raw A/D Count Value $\pm 100$ mVDC (Model 965EN-4006 Only)
40120	0077	CH4 Cal Hi Range 9	Raw A/D Count Value $\pm 1$ VDC (Model 965EN-4006 Only)
40121	0078	CH4 Cal Lo Range 9	Raw A/D Count Value $\pm 1$ VDC (Model 965EN-4006 Only)
40122	0079	CH5 Cal Hi Range 0	Raw A/D Count Value J Type TC (Model 965EN-4006 Only)
40123	007A	CH5 Cal Lo Range 0	Raw A/D Count Value J Type TC (Model 965EN-4006 Only)
40124	007B	CH5 Cal Hi Range 1	Raw A/D Count Value K Type TC (Model 965EN-4006 Only)
40125	007C	CH5 Cal Lo Range 1	Raw A/D Count Value K Type TC (Model 965EN-4006 Only)

Ref	Addr.	Description	Data Type/Format
<b>Holding Registers (4x References, Read/Write)</b>			
40126	007D	CH5 Cal Hi Range 2	Raw A/D Count Value T Type TC (Model 965EN-4006 Only)
40127	007E	CH5 Cal Lo Range 2	Raw A/D Count Value T Type TC (Model 965EN-4006 Only)
40128	007F	CH5 Cal Hi Range 3	Raw A/D Count Value R Type TC (Model 965EN-4006 Only)
40129	0080	CH5 Cal Lo Range 3	Raw A/D Count Value R Type TC (Model 965EN-4006 Only)
40130	0081	CH5 Cal Hi Range 4	Raw A/D Count Value S Type TC (Model 965EN-4006 Only)
40131	0082	CH5 Cal Lo Range 4	Raw A/D Count Value S Type TC (Model 965EN-4006 Only)
40132	0083	CH5 Cal Hi Range 5	Raw A/D Count Value E Type TC (Model 965EN-4006 Only)
40133	0084	CH5 Cal Lo Range 5	Raw A/D Count Value E Type TC (Model 965EN-4006 Only)
40134	0085	CH5 Cal Hi Range 6	Raw A/D Count Value B Type TC (Model 965EN-4006 Only)
40135	0086	CH5 Cal Lo Range 6	Raw A/D Count Value B Type TC (Model 965EN-4006 Only)
40136	0087	CH5 Cal Hi Range 7	Raw A/D Count Value N Type TC (Model 965EN-4006 Only)
40137	0088	CH5 Cal Lo Range 7	Raw A/D Count Value N Type TC (Model 965EN-4006 Only)
40138	0089	CH5 Cal Hi Range 8	Raw A/D Count Value $\pm 100\text{mVDC}$ (Model 965EN-4006 Only)
40139	008A	CH5 Cal Lo Range 8	Raw A/D Count Value $\pm 100\text{mVDC}$ (Model 965EN-4006 Only)
40140	008B	CH5 Cal Hi Range 9	Raw A/D Count Value $\pm 1\text{VDC}$ (Model 965EN-4006 Only)
40141	008C	CH5 Cal Lo Range 9	Raw A/D Count Value $\pm 1\text{VDC}$ (Model 965EN-4006 Only)
40142	008D	CJC0 Cal Hi	Raw A/D Count Value
40143	008E	CJC0 Cal Lo	Raw A/D Count Value
40144	008F	CJC1 Cal Hi	Raw A/D Count Value
40145	0090	CJC1 Cal Lo	Raw A/D Count Value
40146	0091	CJC2 Cal Hi	Raw A/D Count Value (Model 965EN-4006 Only)
40147	0092	CJC2 Cal Lo	Raw A/D Count Value (Model 965EN-4006 Only)
40148	0093	Ideal Range 0 Hi	Ideal A/D Count Value J TC Type
40149	0094	Ideal Range 0 Lo	Ideal A/D Count Value J TC Type
40150	0095	Ideal Range 1 Hi	Ideal A/D Count Value K Type TC
40151	0096	Ideal Range 1 Lo	Ideal A/D Count Value K Type TC
40152	0097	Ideal Range 2 Hi	Ideal A/D Count Value T Type TC
40153	0098	Ideal Range 2 Lo	Ideal A/D Count Value T Type TC

## Register Map

**Model 965EN-4006**  
**Model 965EN-4004**

Shaded 4xxxx registers are Read-Only.

## Register Map

**Model 965EN-4006**  
**Model 965EN-4004**

*Shaded 4xxxx register entries  
are Read-Only.*

Ref	Addr.	Description	Data Type/Format
<b>Holding Registers (4x References, Read/Write)</b>			
40154	0099	<i>Ideal Range 3 Hi</i>	<i>Ideal A/D Count Value R Type TC</i>
40155	009A	<i>Ideal Range 3 Lo</i>	<i>Ideal A/D Count Value R Type TC</i>
40156	009B	<i>Ideal Range 4 Hi</i>	<i>Ideal A/D Count Value S Type TC</i>
40157	009C	<i>Ideal Range 4 Lo</i>	<i>Ideal A/D Count Value S Type TC</i>
40158	009D	<i>Ideal Range 5 Hi</i>	<i>Ideal A/D Count Value E Type TC</i>
40159	009E	<i>Ideal Range 5 Lo</i>	<i>Ideal A/D Count Value E Type TC</i>
40160	009F	<i>Ideal Range 6 Hi</i>	<i>Ideal A/D Count Value B Type TC</i>
40161	00A0	<i>Ideal Range 6 Lo</i>	<i>Ideal A/D Count Value B Type TC</i>
40162	00A1	<i>Ideal Range 7 Hi</i>	<i>Ideal A/D Count Value N Type TC</i>
40163	00A2	<i>Ideal Range 7 Lo</i>	<i>Ideal A/D Count Value N Type TC</i>
40164	00A3	<i>Ideal Range 8 Hi</i>	<i>Ideal A/D Count Value ±100mVDC</i>
40165	00A4	<i>Ideal Range 8 Lo</i>	<i>Ideal A/D Count Value ±100mVDC</i>
40166	00A5	<i>Ideal Range 9 Hi</i>	<i>Ideal A/D Count Value ±1VDC</i>
40167	00A6	<i>Ideal Range 9 Lo</i>	<i>Ideal A/D Count Value ±1VDC</i>
40168	00A7	<i>CJC0 Hi</i>	<i>Ideal CJC0 A/D Count Value</i>
40169	00A8	<i>CJC0 Lo</i>	<i>Ideal CJC0 A/D Count Value</i>
40170	00A9	<i>CJC1 Hi</i>	<i>Ideal CJC1 A/D Count Value</i>
40171	00AA	<i>CJC1 Lo</i>	<i>Ideal CJC1 A/D Count Value</i>
40172	00AB	<i>CJC2 Hi (965EN- 4006)</i>	<i>Ideal CJC2 A/D Count Value</i>
40173	00AC	<i>CJC2 Lo (965EN- 4006)</i>	<i>Ideal CJC2 A/D Count Value</i>
40174	00AD	<i>Reserved</i>	<i>Reserved</i>
40175	00AE	<i>Reserved</i>	<i>Reserved</i>
40176	00AF	<i>Reserved</i>	<i>Reserved</i>
40177	00B0	<i>Reserved</i>	<i>Reserved</i>
40178	00B1	<i>Reserved</i>	<i>Reserved</i>
40179	00B2	<i>Reserved</i>	<i>Reserved</i>



Ref	Addr.	Description	Data Type/Format
<b>Holding Registers (4x References, Read/Write)</b>			
40180	00B3	Span Cal Register	A 16-Bit value whose bit position when set indicates the channel to be calibrated for span. For example: to calibrate span of channel 0, write 0001H to this register. To calibrate span of channel 5, write 0020H to this register.
40181	00B4	Zero Cal Register	A 16-Bit value whose bit position when set indicates the channel to be calibrated for zero. For example: to calibrate zero of channel 0, write 0001H to this register. To calibrate zero of channel 5, write 0020H to this register.
40182	00B5	Reserved	Reserved
40183	00B6	Tref Cal Register	A 16-Bit value whose bit position when set indicates the CJC channel to be calibrated. For example: to calibrate CJC0, write 0001H to this register. To calibrate CJC1, write 0002H to this register. To calibrate CJC2, write 0004H to this register. <b>IMPORTANT:</b> You must FIRST write 5E2AH into the Calibration Access Register (Register 40021) before attempting calibration.
43001 . . .		This block Mirrors 3xxxx Registers.	Refer to Register Mirroring. 3xxxx Input Registers are mapped to the 43xxx Holding Register space using an address offset of 43000.

## Register Map

**Model 965EN-4006**  
**Model 965EN-4004**

**IMPORTANT:** You must FIRST write 5E2AH into the Calibration Access Register (Register 40021) before attempting span, zero, or Tref calibration via these registers.

### Notes (Memory Map):

With 16-bit signed integers, a count of 0-7FFFH is a positive number, while 8000-FFFFH is a negative number. The ±1V DC input range values are represented by ±20000 counts. For example when using bipolar devices, -1V, 0V, & +1V are represented by integer values – 20000, 0, & +20000, respectively. Similarly, when connected to a unipolar device, integer values from 0-20000 counts represent 0-1V, excluding negative values. A 16-bit signed integer value is also used to represent the range of a TC type measured in degrees C with resolution of 0.1°C/lb. For example, a JTC type has a range of -210 to 760C, which read -2100 to 7600 counts within the data register respectively. . (See Table 1: Supported TC Types, Ranges, and Accuracy for Upscale or Downscale break detection)

## SPECIFICATIONS

These DIN-rail mount, industrial Ethernet, analog input modules will condition up to 4 or 6 thermocouple or millivolt input signals according to the model, and provide an isolated 10/100BaseT Ethernet port for monitoring and control. Units are DC-powered and include reverse polarity protection. Analog inputs (as a group), network, and power are isolated from each other. Input channels share common. Non-volatile reprogrammable memory in the module stores configuration and calibration information.

### Model Numbers

965EN-4006 (4 mV/TC)

965EN-4004 (6 mV/TC)

The BusWorks model prefix "900" denotes the Series 900 network I/O family. The "EN" suffix denotes EtherNet. Select 965EN for mV/TC input types. The four digit suffix of this model number represents the following options, respectively: "4" = Ethernet; "0" = Default; "04" or "06" = 4 or 6 Channels, respectively.

### Analog Inputs

Four or six millivolt or thermocouple input channels per model. Input channels of this unit can be configured to accept one of several input ranges below. The unit must be wired and configured for the intended input type and range (see Connections section for details). The following paragraphs summarize this model's input types, ranges, and applicable specifications.

**Thermocouple (See Table 1):** Configurable for J, K, T, R, S, E, B, and N thermocouple types as shown in Table 1. Linearization, Cold-Junction Compensation (CJC), and open circuit or lead break detection are included. The first three channels must be configured for the same thermocouple type, but this can be different from the last three channels which must be the same type. The selection of Upscale or Downscale break detection applies to all channels together.

**Table 1: Supported TC Types, Ranges, and Accuracy**

TC	TC Material	ISA/ANSI Color	°C Temp Range	Typical <sup>1</sup> Accuracy
J	+Iron, -Constantan	White/ Red	-210 to +760°C	±0.5°C
K	+Chromel, -Alumel	Yellow/ Black	-200 to +1372°C	±0.5°C
T	+Copper, -Constantan	Blue/ Red	-260 to +400°C	±0.5°C
R	+Pt/13%Rh, -Constantan	Black/ Red	- 50 to +1768°C	±1.0°C
S	+Pt/10%Rh, -Constantan	Black/ Red	- 50 to +1768°C	±1.0°C
E	+Chromel, -Constantan	Purple/ Red	-200 to +1000°C	±0.5°C
B	+Pt/10%Rh, -Pt/6%Rh	Gray/ Red	+260 to 1820°C	±1.0°C
N	+Nicrosil, -NISIL	Orange/ Red	-230 to -170°C; -170 to +1300°C	±1.0°C ±0.5°C

**TIP:** Best accuracy with CJC ON is obtained by using channels 0, 2, and 4 (the channels closest to the CJC sensors).

**Note 1 (Table 1):** Accuracy is given with CJC switched off. CJC inaccuracy must be added to the inaccuracy numbers in Table 1 to determine potential overall inaccuracy. Relative inaccuracy with CJC enabled may increase by as much as ±1.0°C during warmup period, but will be ±0.2°C typical (±0.5°C maximum) after one hour.

**TC Input Reference Test Conditions:** TC Type J with a 10mV minimum span (e.g. Type J with 200°C span); Ambient = 25°C; Module mounted upright with 1 inch minimum air space on both sides of module.

**Analog Inputs**

**TC Break Detection:** Can be selected for Upscale or Downscale open sensor or lead break detection. Break detent selection applies to all channels simultaneously and cannot be disabled.

**TC Input Bias Current:** ±25nA typical (TC break).

**Thermocouple Reference (CJC):** Better than ±0.5°C at 25°C (see Note1 of Table 1). Ambient effect of the CJC is ±0.01°C/°C typical.

**Note:** Cold Junction Compensation may be switched off to permit the direct connection of a mV source to the input for ease of calibration. For best results, allow the module to warm up for an hour prior to calibrating CJC.

**TC Linearization:** Within ±0.25°C of the NIST tables.

**DC Voltage (See Table 2):** Can be configured for the bipolar DC voltage range of ±100mVDC or ±1V DC.

**Input bias current:** 25nA typical.

**Voltage Input Reference Test Conditions:** ±100mV input range with 10mV span; Ambient Temperature = 25°C.

**Input Over-Voltage Protection:** Bipolar Transient Voltage Suppressers (TVS), 18V clamp level typical.

**Accuracy:** TC accuracy is listed in Table 1. CJC accuracy is ±0.5°C. Voltage accuracy is better than ±0.05% of span. This includes the effects of repeatability, terminal point conformity, and linearization, but does not include sensor error.

**Measurement Temperature Drift:** Better than ±60ppm/°C (±0.006%/°C).

**Analog to Digital Converter (A/D):** A 16-bit Σ-Δ converter.

**Resolution:** Given in Table 2 below per applicable range.

Input Range	Effective Resolution
±100mV DC	0.005% or 1 part in 20000
±1V DC	0.005% or 1 part in 20000
Thermocouples	0.1°C (0.18°F)

**Input Conversion Rate:** 80ms per input channel, 320ms for four input channels, 480ms for six input channels, typical. Additionally, CJC channels are read every 10 seconds (at 80ms each, 160ms for two, or 240ms for three).

**Input Filter:** Normal mode filtering, plus digital filtering optimized and fixed per input range within the Σ-Δ ADC.

**Input Filter Bandwidth:** -3dB at 3Hz, typical.

**Noise Rejection (Normal Mode):** 40dB @ 60Hz, typical with 100Ω input unbalance.

**Noise Rejection (Common Mode):** 140dB @ 60Hz, typical with 100Ω input unbalance.

**Data Types:** Input range (±1V, ±100mVDC) - A 16-bit signed integer value with resolution of 0.005%/lsb. ±20000 is used to represent ±100%. For example, -100%, 0%, and +100% are represented by decimal values -20000, 0, and 20000, respectively. Temperature (TC Inputs) - A 16-bit signed integer value with resolution of 0.1°C/lsb. For example, a value of 12059 is equivalent to 1205.9°C, a value of -187 equals -18.7°C. The maximum possible temperature range is -3276.8°C to +3276.7°C.

**General Specifications**

## General Specifications

**Note:** Channels 0, 1, & 2, and channels 3, 4, & 5 (every group of 3 channels) must share the same input configuration, but this configuration may vary between the two groups. Break detection detent applies to all channels together. CJC 0 is used for channels 0 & 1, CJC 1 for channels 2 & 3, and CJC 2 for channels 4 & 5. All parameterization bytes take effect immediately.

## Enclosure & Physical

**Dimensions:** 1.05 inches wide, 4.68 inches tall, 4.35 inches deep. Refer to the dimensions drawing at the front of this manual.

**DIN Rail Mount:** Type EN50022; "T" rail (35mm).

**I/O Connectors:** Removable plug-in type terminal blocks rated for 15A/300V; AWG #12-24 stranded or solid copper wire.

**Network Connector:** 8-pin RJ-45 connector socket with metal shield (shield is bypassed to earth ground at the GND terminal via an isolation capacitor and TVS). Connections are wired MDI, as opposed to MDI-X. You must use a CAT-5 crossover cable to connect this module to a PC. Otherwise you may use an auto-crossing Ethernet switch, such as the Acromag 900EN-S005 to make connections.

RJ-45	Signal (MDI)	Description
1	Tx+	Transmit Positive
2	Tx-	Transmit Negative
3	Rx+	Receive Positive
4	Not Used	Connects to Pin 5
5	Not Used	Connects to Pin 4
6	Rx-	Receive Negative
7	Not Used	Connects to Pin 8
8	Not Used	Connects to Pin 7

**Case Material:** Self-extinguishing NYLON type 6.6 polyamide thermoplastic UL94 V-2, color beige; general purpose NEMA Type 1 enclosure.

**Printed Circuit Boards:** Military grade FR-4 epoxy glass.

**Shipping Weight:** 1 pound (0.45 Kg) packed.

## Agency Approvals

**Safety Approvals:** : UL Listed (USA & Canada). Hazardous Locations- Class I, Division 2, Groups A, B, C, D. Consult factory.

**ATEX Certified:** Assessment by TUV Rheinland of North of America, Inc.

per  
ATEX Directive 94/9/EC.  
Ex nA IIC T4 Gc  
TUVNA 14 EX 0001X  
X = Special Conditions

- 1) "WARNING-EXPLOSION HAZARD-DO NOT MAKE OR BREAK CONNECTIONS IN HAZARDOUS LOCATIONS OR AREAS"
- 2) "Warning: Must be installed in suitable enclosure with an Ingress Protection of IP54 minimum, in Hazardous Locations or Areas"

## Environmental

**CAUTION:** Do not exceed 36VDC peak, to avoid damage to the module.

**Operating Temperature:** -25°C to +70°C (-13°F to +158°F).

**Storage Temperature:** -40°C to +85°C (-40°F to +185°F).

**Relative Humidity:** 5 to 95%, non-condensing.

**Power Requirements:** 15-36V DC SELV (Safety Extra Low Voltage). Observe proper polarity. See table for current.

Supply	965EN-4004/4006 Current Draw
15V	109mA Typical, 120mA Maximum
18V	91mA Typical, 100mA Maximum
24V	71mA Typical, 78mA Maximum
36V	52mA Typical, 57mA Maximum

**CAUTION:** Risk of Electric Shock – More than one disconnect switch may be required to de-energize equipment before servicing.

**Isolation:** Input channels (as a group), power, and network circuits are isolated from each other for common-mode voltages up to 250VAC, or 354V DC off DC power ground, on a continuous basis (will withstand 1500VAC dielectric strength test for one minute without breakdown). Complies with test requirements of ANSI/ISA-82.01-1988 for voltage rating specified.

**Installation Category:** Designed to operate in an installation in a Pollution Degree 2 environment with an installation category (over-voltage category) II rating.

**Electromagnetic Interference Immunity (EMI):** Unit has demonstrated measurement shift less than  $\pm 0.25\%$  of input span with interference from switching solenoids, commutator motors, and drill motors.

#### **Electromagnetic Compatibility (EMC) -**

##### **Immunity Per European Norm BS EN 61000-6-2:2005:**

**Electrostatic Discharge (ESD) Immunity:** 4KV direct contact and 8KV air-discharge to the enclosure port per IEC61000-4-2.

**Radiated Field Immunity (RFI):** 10V/M, 80 to 1000MHz AM, 1.4 to 2GHz 3V/M, and 2 to 2.7GHz 1V/M, per IEC61000-4-3.

**Electrical Fast Transient Immunity (EFT):** 2KV to power, and 1KV to signal I/O per IEC61000-4-4.

**Conducted RF Immunity (CRFI):** 10Vrms, 150KHz to 80MHz, per IEC61000-4-6.

**Surge Immunity:** 0.5KV per IEC61000-4-5.

##### **Emissions Per European Norm BS EN 61000-6-4:2007**

**Radiated Frequency Emissions:** 30 to 1000MHz per CISPR16 Class A

**Electromagnetic Compatibility (EMC):** CE marked, per EMC Directive 2004/108/EC. Consult factory.

##### **Immunity per BS EN 61000-6-2:**

- 1) Electrostatic Discharge Immunity (ESD), per IEC 61000-4-2.
- 2) Radiated Field Immunity (RFI), per IEC 61000-4-3.
- 3) Electrical Fast Transient Immunity (EFT), per IEC 61000-4-4.
- 4) Surge Immunity, per IEC 61000-4-5.
- 5) Conducted RF Immunity (CRFI), per IEC 61000-4-6.

##### **Emissions per BS EN 61000-6-4:**

- 1) Enclosure Port, per CISPR 16.
- 2) Low Voltage AC Mains Port, Per CISPR 16.
- 3) Telecom / Network Port, per CISPR 22.

**WARNING:** This is a Class A product. In a domestic environment, this product may cause radio interference in which the user may be required to take adequate measures.

**IMPORTANT:** Power, input, and output (I/O) wiring must be in accordance with Class I, Division 2 wiring methods of Article 501-4(b) of the National Electrical Code, NFPA 70 for installations in the US, or as specified in

**External Fuse:** Select a high surge tolerant fuse rated for 1A or less to protect unit.

## **Environmental**

*Input channels are not isolated channel-to-channel, except for small common-mode voltage differences within  $\pm 4V$ .*

*These limits represent the minimum requirements of the standard, but product has typically been tested to comply with higher standards in some cases.*

## **EMC – CE Marked**

section 18-1J2 of the Canadian Electrical Code for installations within Canada and in accordance with the authority having jurisdiction.

**This equipment is suitable for use in Class I, Division 2, Groups A, B, C, and D, or non-hazardous locations only.**

**WARNING – EXPLOSION HAZARD** – Substitution of any components may impair suitability for Class I, Division 2.

**WARNING – EXPLOSION HAZARD** – Do not disconnect equipment unless power has been switched off or the area is known to be non-hazardous.

## Ethernet Interface

**Connector:** Shielded RJ-45 socket, 8-pin, 10BaseT/100BaseTX.

**Wiring:** Wired MDI. Unit does NOT support auto-crossover.

**Protocol:** Modbus TCP/IP w/Web Browser Configuration.

**IP Address:** Default static IP address is 128.1.1.100.

**Port:** Up to 10 sockets supported, uses port 502 (reserved for Modbus).

**Transient Protection:** Transient Voltage Suppressors (TVS) are applied differentially at the transmit and receive channels. Additionally, the metal shield is coupled to the earth ground terminal via an isolation capacitor and TVS.

**Data Rate:** Auto-sensed, 10Mbps or 100Mbps.

**Duplex:** Auto-negotiated, Full or Half Duplex.

**Compliance:** IEEE 802.3, 802.3u, 802.3x.

**Modbus TCP/IP Protocol Support:** Uses built-in web pages for configuration and control over ethernet via a standard web browser. Up to 10 sockets may be selected. The module uses the standard Modbus TCP/IP port number 502.

**Rx/Tx Memory:** 8K bytes of SRAM for receive/transmit buffers (FIFO).

**Communication Distance:** The distance between two devices on an Ethernet network is generally limited to 100 meters using recommended copper cable. Distances may be extended using hubs, switches, or fiber optic transmission. However, the total round trip delay time must not exceed 512 bit times for collision detection to work properly with CSMA/CD (half-duplex).

**Port Status Indicators:** Green LED indicates link status (ON if auto-negotiation has successfully established a connection), yellow LED indicates activity (ethernet connection is busy/traffic is present).

**Address:** The module IP address can be preset by the user (static) and loaded from internal non-volatile memory, or it can be automatically acquired at startup via a network server using a BOOTP (Bootstrap Protocol), or DHCP (Dynamic Host Configuration Protocol). The unit also includes a default mode toggle switch to cause the module to assume a "known" fixed static IP address of 128.1.1.100 for troubleshooting purposes.

*Refer to Acromag Application Note 8500-734 for instructions on how to change the IP address of your PC network interface card in order to talk to an Acromag module.*

## Controls & Indicators

### LED Indicators:

**RUN (Green)** - Constant ON if power is on and unit is OK. Continuous flashing ON/OFF indicates unit is in "wink" ID mode.

**ST (Yellow)** – Blinks ON/OFF in default communication mode. Stays ON if any input signal is out of range. Note that over-range indication may mask default mode indication. Thus, open channels should be terminated, since break detection (open channel) can cause over-range indication.

**LINK (Green)** – Indicates Ethernet *link* status (ON if auto-negotiation has successfully established a connection).

**ACT (Yellow)** – Indicates Ethernet *activity* (Ethernet connection is busy/traffic is present).

#### Controls:

**Reset/Default Address Switch:** This momentary toggle switch is located on the front panel and is used to either reset the module (toggle right), or toggle the module into, or out of Default Communication Mode (toggle left). In Default Mode, the module assumes the fixed static IP address “128.1.1.100”, a default subnet mask “255.255.255.0”, a default username of “User”, and a default password of “password00”. This switch can also be used to restore the module to its initial factory configuration by holding this switch in its default position while powering up the unit (see “Getting Out Of Trouble” in the Troubleshooting section for more information).

#### Controls & Indicators

The minimum cable required for full operation of this device is Category 5. The term “Category” refers to classifications of UTP (Unshielded Twisted Pair) and STP (Shielded Twisted Pair) cables. There are 3 main categories of cable – Category 3, Category 4, and Category 5. The differences in classification is found in their electrical performance and this is documented in the TIA/EIA 568-A standard.

#### ACCESSORY CABLES

This device is designed for use in harsh industrial environments. Acromag recommends the use of shielded cable when wiring to this device. Select STP (Shielded Twisted Pair) cable rather than UTP (Unshielded Twisted Pair). The use of shielded cable will help protect the data being transmitted from harmful EMI (Electromagnetic Interference) and RFI (Radio Frequency Interference). It will also help to lower your radiated emissions by keeping the cable from emitting EMI and RFI.

There are two types of cable conductors: solid cable and stranded cable. Stranded cables are more flexible than solid cables. But since attenuation is higher for stranded cables than solid conductor cables, these are generally reserved for short runs and patch applications less than 6 meters.

Currently there are two types of shielding employed in Category 5 STP cable: single-shielded and double-shielded. Both of these cables have the same core and jacket as UTP cables, but also include a thin foil outer shield that covers all four twisted-wire pairs. Variations may include a drain wire that encircles the outer jacket. A double-shielded version adds an outer wire screen that surrounds the foil shield and also functions as a drain wire. The drain wire or wire screen typically makes contact at each end of the cable with the metal shield around special RJ45 plug connectors. This shield then makes contact with the metal shield of shielded RJ45 sockets. The socket shield may make direct contact with earth ground, or it may be capacitively coupled to earth ground. In the Acromag 9xxEN modules, it makes contact with earth ground via a high voltage capacitor and transient voltage suppressor. In addition to separately isolating the shield, this helps to minimize radio frequency and electromagnetic interference, and has the added benefit of protection from ESD (Electro-Static Discharge).

Further, Acromag recommends the use of *enhanced* Category 5 cable (CAT-5e). This cable has all the characteristics of Category 5, but includes enhancements that help to minimize crosstalk. Category 5e cable has a greater number of turns-per-inch in its twisted pairs and its performance is also more suitable for applications that make use of all four wire pairs for simultaneous bidirectional data transmission (full-duplex). As such, it is

rated for frequencies up to 200MHz, double the rate of Category 5. This cable is defined in TIA/EIA-568A-5 (Addendum 5).

## Patch Cable & Crossover Cable

Acromag offers the following cable accessories for use with this module:

**Cable Model 5035-355** – A yellow, 3 foot long, single-shielded Category 5e STP patch cable with drain wire and an RJ45 plug at both ends. Use this cable to connect an Acromag 9xxEN I/O module to the Acromag 900EN-S005 switch.

**Cable Model 5035-360** – A green, 5 foot long, single-shielded Category 5e STP crossover cable with a drain wire and an RJ45 plug at both ends. This cable performs the Ethernet crossover function and is used to connect a PC directly to an Acromag Series 9xxEN I/O module.

Note that you do not need to use a crossover cable to connect your PC to this module if the Acromag 900EN-S005 switch is used between the PC and module, as the switch is auto-crossing. However, you must use a crossover cable when directly connecting your PC to a Series 9xxEN I/O Module without the use of an auto-crossing switch or hub.

You may obtain cable in other lengths and colors as required for your application from other vendors. For example, shielded CAT-5e cable is available from the following vendors:

- L-com Connectivity Products, [www.L-com.com](http://www.L-com.com)
- Pro-Link, [www.prolink-cables.com](http://www.prolink-cables.com)

For very noisy environments or in the presence of strong electrical fields, you can obtain double-shielded CAT-5e cable and shielded RJ45 plugs from the following vendors:

- L-com Connectivity Products, [www.L-com.com](http://www.L-com.com), see cable model TFSC2004 and shielded plug T8P8CSR.
- Regal Electronics, [www.regalusa.com](http://www.regalusa.com), see shielded plug model 1003B-8P8CSR-C5.

Complete premium double-shielded Category 5e standard and crossover cables in variable lengths can be obtained from Lumberg at [www.lumbergusa.com](http://www.lumbergusa.com) (refer to their etherMate line). For example, specify RJ45S-RJ45S-656/B/3M for a double-shielded, 3 meter straight cable. Specify RJ45S-RJ45S-656/BX/3M for a double-shielded, 3 meter crossover cable.



## Revision History

The following table shows the revision history for this document:

Release Date	Version	EGR/DOC	Description of Revision
21 JUN 12	H	TPH/KLK	Updated input over/under range specifications (ECN 12A011).
04 JAN 13	J	CAP/BNB	Added ATEX and updated CE specifications (ECN 12L019).
21 APR 14	K	CAP/SRW	Update ATEX per latest standards (ECO 14D012).
09 JAN 2019	L	CAP/ARP	Update "WARNING - EXPLOSION HAZARD - Substitution of <u>any</u> components..." per uL.

**NOTES:**