


# IP235 & 230 BLOCK DIAGRAM



NOTE: All analog output channels are referenced to analog ground. To avoid ground loops do not connect grounded loads to the negative side of the output.

\* These functions are only available in the IP235 module.  
 \*\* Channels 4-7 are only available on 8-channel models