



NOTE: ALL ANALOG OUTPUT CHANNELS ARE REFERENCED TO ANALOG GROUND. TO AVOID GROUND LOOPS DO NOT CONNECT GROUNDED LOADS TO THE NEGATIVE SIDE OF THE OUTPUT.

*EACH CHANNEL HAS A DEDICATED INTERNAL TIMER, FIFO MEMORY, & TRIGGER HARDWARE.

** CHANNELS 4-7 ARE ONLY AVAILABLE ON 8-CHANNEL MODELS.

IP236 BLOCK DIAGRAM

4501-736A