

Transmitters: ST130 Series

Mounting Accessories Enclosures, adapters, mounting kits





Simplifies mounting of ST130 Series transmitters ◆ Ideal for mounting in the field or in a control room

Description

For your convenience, Acromag offers a variety of head-mount enclosures and other mounting accessories to simplify your system installation.

Ordering Information

NOTE: For more information visit www.acromag.com.

Mounting Accessories

Replacement mounting Kit - Includes two (2) M4 mounting screws, (2) 6-32 mounting screws, and (2) two relief springs for mounting an ST130 transmitter in a DIN Form B connection head.

4001-115K

Explosion-Proof Aluminum Connection Head -FM/FMC, Class I, Division 1, Groups A, B, C, D, T6; Class II, III, Division 1, Groups E, F, G, T6; NEMA 4 rated. Includes M4 mounting screws and springs.

4001-116K

Explosion-Proof Stainless Steel Connection Head -FM/FMC, Class I, Division 1, Groups A, B, C, D, T6; Class II, Division 1, Groups E, F, G, T6; Class III, NEMA 4X rated. Includes M4 mtg screws and springs.

4001-117K

General-Purpose Aluminum Connection Head -NEMA 4X and IP68 rated. Includes M4 mounting screws and springs.

4001-119K

General-Purpose Cast Iron Connection Head -NEMA 4X rated. Includes M4 mtg screws and springs.

ST130-DIN


Series ST DIN Rail Adapter - Includes a DIN rail bracket with mounting screws that connects a ST130 transmitter to a 35mm T-type or G-type DIN rail. Includes M4 mounting screws and springs.




ST130-MTG Mounting Kit


Required to mount ST130 transmitter in connection head enclosure.








Dimensions: 4001-115K and 4001-116K







Tel: 877-214-6267 ■ sales@acromag.com ■ www.acromag.com ■ 30765 S Wixom Rd, Wixom, MI 48393 USA